

HOW TO USE THE YARN TWISTER

Three-staged pitches (2.0 cm, 1.5 cm, 1.0 cm) can be altered by changing belt hanging position as illustrated below.



BE SURE TO OPERATE THE HANDLE IN CLOCKWISE DIRECTION

FIX TWISTER BY THE CLAMP

INSERT TENSION HOLDER

Direction of twist can be altered by changing hanging manner of belt as illustrated below.



—BOBBIN ADJUSTING DIAL—

to adjust tension of second yarn against main yarn.



ATTACH TENSION DIAL

—TENSION DIAL—

to adjust tension of main yarn

Direction "—" indicates weaker tension.
Direction "+" indicates stronger tension.



HOW TO THREAD AND TWIST TWO STRANDS OF YARN

HOW TO WIND SECOND YARN

Locate main yarn between tension discs.

1

Tie the two strands of yarn together.

2

Insert yarn hook through center hole of the pulley. Then, hook a knot of two yarns and pull it out.

3



Pass the yarns under yarn guide, and up into yarn leader roll by raising up yarn presser with your finger, and then replace yarn presser in position.

1



Remove belt placed on stopped pulley "A" and mount bobbin onto bobbin shaft.

2



Wind second yarn on bobbin by hand several times. Then the second yarn by left hand and wind it up automatically by separating handle with right hand.

3



Take off the bobbin when the winding finished.

4



Mount firmly the bobbin with the second yarn onto rotating shaft, and place the belt to the original position.

