

Table of contents

DESCRIPTION	1-9
THE MACHINE	1
THE CARRIAGE	î
ACCESSORIES	2
HOW TO SET UP	
YOUR KNITTING MACHINE.	3
THE NEEDLE BED	6
THE NEEDLES	6
NEEDLE POSITIONS	6
GRADUATED SCALE	7
STITCH SIZE DIAL	7
ROW COUNTER	7
NEEDLE SELECTOR SWITCH	8
STITCH FORMATION	9
KNITTING	10-28
HINTS BEFORE KNITTING	
CASTING-ON	13
STOCKINETTE STITCH	17
HOW TO USE THE EYELET TOOL	18
HEM IN 1/1 MOCK RIB	20
SIMPLE INCREASE	22
ITALIAN INCREASE	22
INCREASING SEVERAL STITCHES	
SIMPLE DECREASE	24
ITALIAN DECREASE DECREASING SEVERAL STITCHES	24
NECKLINES	25 26
PART ROW KNITTING	27
HORIZONTAL BUTTONHOLES	28
ANOTHER WAY OF DOING	29-34
CHAIN CASTING ON. THIS IS A CLOSED CASTING ON	-
CASTING OFF	29
CASTING-OFF HOW TO MAKE RIBBING	32
ASSEMBLING	6-37
INVISIBLE SEAMS	36
COLLAR SEAMS, FINISHING BANDS	37
GRAFTING:	37
	1000
WHAT TO DO IF 3	8-42
A STITCH IS DROPPED,	
OR NOT KNITTED	38
A STITCH DROPS SEVERAL ROWS	38
YOU WANT TO UNDO ONE	
OR MORE ROWS	40
CARE AND MAINTENANCE	40
CARE AND MAINTENANCE	42
FANCY PATTERNS	3-50
INTARSIA	43
WEAVING EFFECT	44
PULLED UP STITCHES	45
FAIR ISLE	46
I ID STITCH	
SLIP STITCH	48
SLIP STITCH	49
SLIP STITCH	20,000



ACCESSORIES



HOW TO SET UP YOUR KNITTING MACHINE





















































ANOTHER WAY OF DOING














MAKING UP INVISIBLE SEAMS • Sew seams on the right side • Put the edges of the two pieces by side. Pass a tapestry needle threaded with matching yarn, through the bar formed between the edge stitch and the second stitch on the right side. Pass the needle through the bar formed between the left hand edge stitch and the second stitch. • Pull these two bars together. Continue, taking the bars at each side, one at a time.



WHAT TO DO IF...

A STITCH DROPS OR IS NOT KNITTED



- Rehang the dropped stitch behind the latch and the unknitted yarn on the hook.
- Pull the needle heel down to draw the yarn through.

A STITCH DROPS SEVERAL ROWS



 Insert the hook and latch needle tool a few rows under the dropped stitch, from the back of the knitting.



- Push the tool upwards until the dropped stitch slides behind the latch.
- Take the yarn from the row above onto the hook of the tool.



 Pull the tool downwards until the latch closes and a new stitch is formed.



• When the last loop of yarn has been knitted, transfer the stitch onto the needle.





To remove the needle: close the latcht (it prevents the needle hook from catching the needle retaining spring located under the slide rail). Pull the needle out by the heel, towards the back.

 IMPORTANT: If the latch is broken or badly bent, clip the hook and latch from the needle with a wire cutters before changing.



- To replace the needle open the latch and slide it under the graduated scale, pressing on the needle body to make insertion easier.
- Push the needle rod back into place (bent end to the front) to lock all needles in place

Maintenance

Care and maintenance

- A Regularly remove the dust and the fluff from your machine, especially the needle grooves, with a nylon brush.
- B With a clean cloth soaked with oil (special oil for sewing or knitting machine), lubricate the needle heels. In the same way, lightly lubricate the underside of the carriage. To distribute the oil evenly place needles in position 2. Take the carriage across several times without yarn. Wipe of excess.

FANCY PATTERNS















