







englisch



FORM COMPUTER

PASSAP®




Instruction Book

FORM COMPUTER

- 2 Outline of the FORM COMPUTER
- 3 Fitting the FORM COMPUTER
- 6 The test square
- 7 Choosing the correct programme
- 8 Inserting individual measurements into the programme
- 10 Entering the programme
- 11 Checking the programme
- 12 Knitting with the computer
- 17 Illustrations of 42 garments
- 33 Practical tips
- 36 Various neckbands and polo neck collar
- 39 Programmes for 42 garments

FORM COMPUTER

This is just an outline, for more detailed explanations see pages 14 to 16.



The figures 0–9 have two uses.

- As digits when entering the programme (see page 10).
- As functions while checking the knitting (see next column).

A Display

B ON/OFF switch

C Lock position indicator. Lights up left or right according to position of lock.

Key 9 = GO. Returns computer to working position after it has been in rest position.

Key 8 = STOP. Brings computer to rest position.

Key 7 = ▶ While the indication for "cast on" appears, the left position indicator can be lit up by pressing this Key if one wants to begin with the lock at left.

Key 6 = ◀▶ mirroring. Reverses settings (e.g. would re-set calculations for right front to those required for left front).

Key 5 = < Rolls back programme. When pressed you can enter the number of rows by which you require the programme to be set back. Always press Key E afterwards.

Key 4 = ▷▷▷ fast forward. While "cast on" is displayed and after pressing Key 4 you can advance the programme by the number of rows required. Always press Key E afterwards.

Key 3 = ▷ 1 row forward. Advances the programme by 1 row each time it is pressed.

Key 2 = ▽ knitted rows. While this Key is pressed the number of rows of knitting already completed will be displayed.

Key 1 = →— Inserting a figure. After pressing this Key you can insert a figure during the programme check. Always press Key E afterwards.


Key 0 = Zero. This Key is used to clear any figure not required, during the programme check.

Key C = Clear Key. Clears incorrect figures which are to be replaced by corrected ones.

Key E. After pressing this Key the figure entered immediately previously will be put into store for the computer to use during its calculations.

Fitting the FORM COMPUTER


Fitting the supporting foot to the DUOMATIC 80, DUOMATIC S and DUOMATIC with COLOR



- Remove the locks and edge springs from the beds. Take the machine off the stand and place it upside down on a table.
- As per sketch, slide the connecting plate underneath the edges of the back bed so that the pegs fit into their respective holes.
- Using two of the four largest screws, screw the connecting plate to the inner edge (A).
- Using the two remaining largest screws, screw the support as per sketch to the outer edge and the connecting plate (B).


Fitting the supporting foot to the ELECTRA 2000

(Ask your stockist about fitting the FORM COMPUTER to the ELECTRA M 75 B)



- Use two screws with hexagon heads from the ELECTRA 2000 accessory. Insert the heads of the screws into the holes located at left on the underside of the ELECTRA guide rail. Push the screws to about the middle of the bed.
- Fit the support over the two screws (with the holes as per sketch). Using the two wing nuts from the ELECTRA 2000 accessory, screw the support on, making sure the bent-away parts of the support are facing downwards.


Fitting the mounting bracket



- Insert the two screws of the mounting bracket through the two holes of the supporting foot. Screw on the two knurled nuts from below.

Fitting the FORM COMPUTER

Fitting the driver to the back lock when knitting without the ELECTRA



- Remove the back lock from the bed, and place it upside down on the table with the arrow key at right front.
- Loosen the left pusher retaining cam (A), keeping the two screws and washers.
- Screw on the smaller driver with the bent-away part and two holes as follows:


For the DUOMATIC 80, use the small silvery screws.

For the DUOMATIC, use the small dark-coloured screws.

For the DUOMATIC S, use the black, slim but longer screws, and instead of the pusher retaining cam (A) which the DUOMATIC S does not have, use the two wing nuts which must be held in place while the screws are screwed in.


Note: In this position, the bent-away part of the driver must face to the left as per sketch.

Fitting the driver when using the ELECTRA 2000



- Place the larger driver, which is bent in two places, from above on to the connecting plate of the lock and ELECTRA.
- Insert one of the largest of the four screws from above in the hole and fix it from underneath with a nut.


Fitting the magnet holder to its driver



- Push the magnet holder on to the driver, as per sketch, until it snaps in.


Fitting the FORM COMPUTER

Connecting the FORM COMPUTER to the mounting bracket



- Insert the four pegs on the back of the computer into the four keyhole-shaped openings of the mounting bracket, then press the computer down.
- Connect the adapter to the computer, and lay the wire into the hook on the back of the mounting bracket.

Checking that the distance from the magnet to the FORM COMPUTER is correct




- The distance from the magnet to the lower edge of the FORM COMPUTER must be approximately 3 to 5 mm. An inaccurate distance may lead to errors. Should this be the case, slightly bend the mounting bracket of the FORM COMPUTER.

The Test Square

**Take advantage of what the FORM COMPUTER has to offer:
choose the style of garment you prefer, then add the stitch pattern,
the yarn and the colour you want.**

You have chosen the yarn and the stitch pattern and are now ready to knit the test square. This is vital, for without it the computer cannot work out how many stitches have to be cast on and how many rows have to be knitted.



When you work with the FORM COMPUTER you need **the measurements in millimetres from a test square 40 rows by 40 stitches**.

Note: only the stitches on the front bed are counted. Where a stitch pattern has some needles in non-working position then these needles are counted, too. The test square must be worked over **40 needles as indicated on the needle scale**.

For counting rows always refer to the row counter.

This also applies to double-bed knitting and in particular to tubular where only 20 rows can be seen on the actual piece of knitting whereas the row counter already indicates 40 rows.

The test square is always knitted in the yarn, the pattern, the stitch size and the yarn tension you will be using for your garment.

Casting on and off always with contrast yarn.


After casting on knit approximately 6 to 10 rows in contrast yarn before changing to your main yarn. Then, before you release your knitting, change back to contrast yarn. Knit 10 to 12 rows and release. Do not forget to press your test square if the finished garment is also to be pressed.

When knitting a particularly stretchy piece of material – or for patterns where 40 rows by 40 stitches result in very small test squares – it is recommended that you knit over a width of 80 needles and 80 rows, dividing the resulting measurements by 2.

The test square for the border: When you are knitting a garment with a border (band, welts, etc.) you also have to knit a test square for this so that the computer can work out the rows that have to be knitted. Here, the number of stitches is not important. All that is needed is the measurement, in millimetres, of 40 rows knitted in the stitch pattern selected for the border.

Choosing the correct programme

The programme for each piece of knitting is contained in the corresponding row of figures given in the description for garments. **Each part (i.e. back, front, etc.) must be programmed separately.** When one part is finished the programme has to be cleared and the appropriate one for the next part entered.



Start by taking your own measurements, or those of the person for whom you are going to knit. Look at the chart below, and in the garment descriptions, to see what measurements you need and what individual measurements can be inserted in the programme.

All the measurements are body measurements and therefore the tape measure should fit closely.

A = The bust/chest measurement is taken across the widest part of the bust/chest.

B = The hip size is measured over the widest part of the hips.

C = The total length is taken at the back from the nape of the neck down to the required length of the sweater or dress.

D = The total length of the skirt is measured from the waist-band to where the hem should be.

E = The total length of the sleeves is measured along the extended arm from the shoulder point to the length required.

Note: this also applies to sleeves that are not set in in the normal way, as for example kimono or raglan sleeves.

Shop sizes							
Ladies' sizes			Men's sizes			Children's sizes	
Size	Bust	Hips	Size	Chest		Height	Age
34	84 cm = 33½ ins.	89 cm = 35½ ins.	42	84 cm = 33½ ins.		86 cm = 34 ins.	1
36	87 cm = 34½ ins.	92 cm = 36½ ins.	44	88 cm = 34¾ ins.		92 cm = 36½ ins.	2
38	90 cm = 35½ ins.	95 cm = 37½ ins.	46	92 cm = 36½ ins.		98 cm = 38¾ ins.	3
40	93 cm = 36¾ ins.	98 cm = 38¾ ins.	48	96 cm = 37¾ ins.		104 cm = 41 ins.	4
42	96 cm = 37¾ ins.	101 cm = 39¾ ins.	50	100 cm = 39½ ins.		110 cm = 43¼ ins.	5
44	99 cm = 39 ins.	104 cm = 41 ins.	52	104 cm = 41 ins.		116 cm = 45¾ ins.	6
46	102 cm = 40¼ ins.	107 cm = 42¼ ins.	54	108 cm = 42½ ins.		122 cm = 48 ins.	7
48	108 cm = 42½ ins.	113 cm = 44½ ins.	56	112 cm = 44 ins.		128 cm = 50¼ ins.	8
50	114 cm = 45 ins.	119 cm = 47 ins.				134 cm = 52¾ ins.	9
52	122 cm = 48¼ ins.	128 cm = 50½ ins.				140 cm = 55 ins.	10
54	128 cm = 50½ ins.	134 cm = 52¾ ins.				146 cm = 57½ ins.	11

Inserting individual measurements into the programme

Now compare the measurements you have taken with the chart above which shows usual shop sizes. If your measurements do not correspond exactly with those in the chart choose the **next smaller size** and when you enter the programme insert your own measurements in the places provided for this purpose. The computer will now calculate the garment to your exact measurements, ensuring a perfect fit.

Front of a lady's sweater

34	36	40	44
80	80	80	80
148	148	148	148
132	138	146	154
84	87	93	99
84	87	93	99
195	195	195	195
7	7	7	7
7	7	7	7
38	38	38	38
132	138	146	154
84	87	93	99
34	34	34	34
62	62	63	64
235	236	236	236
7	7	7	7
3	3	3	3
169	169	169	169
153	153	178	178
178	188	188	188
146	129	129	129
7	146	146	146
28	7	7	7
191	27	29	31
146	191	191	191
3	147	148	150
67	3	3	3
191	67	67	67
146	191	191	191
42	146	146	146
0	42	45	47
	0	0	0

mm 40 R
mm 40 sts

mm 40 R
Border

Bust
Shop size
Your bust size in cm

Total length
Shop size
Your total length in cm



Test square

In each programme the 3rd and 4th line are left free for entering the measurements of the test square as follows:

mm 40 R: Measurement in millimetres for 40 rows of your knitting.

mm 40 sts: Measurement in millimetres for 40 stitches of your knitting (or the measurement which results when knitting over a width of 40 needles on the front bed).

mm 40 R Border: The place where **the measurement in millimetres for 40 rows for the border** has to be inserted is specially marked in each programme.

Individual measurements

The measurements are always taken in centimetres. The places where individual measurements can be entered are specially indicated in each programme.


The measurement corresponding to the "shop size" chosen by you can be seen from the line immediately above the corresponding empty line and is expressed in centimetres.

If you do not wish to alter the "shop size" measurements they must still be repeated in the empty line.

Important: You must always enter a figure here. If you skip this position when entering a programme the computer cannot function correctly.


Inserting individual measurements into the programme

When inserting individual measurements the following must be remembered:




Measurements related to the length such as overall length of dresses, sweaters, skirts and sleeves (i.e. measurements referring to rows) **can be increased or decreased**.

Do not forget to adapt the figures of both front and back if you do.



Measurements across (relating to the width) such as bust, chest, hips and sleeve width (i.e. measurements referring to stitches) **can only be enlarged**.


If you make the measurements referring to width smaller by mistake the computer will display the **message ERR 3** instead of CAST ON. In such a case press Key C, followed by Key E. You can now check the programme and amend it as explained on page 11.



Note: If you add to the bust/chest size you will have to increase the upper width of the sleeves by exactly half the centimetres you have added to the bust/chest. If you do not increase the bust/chest measurement do not increase the upper sleeve width either, or the sleeve will not fit into the armhole.

Entering the programme

Before you connect your transformer check that the voltage corresponds to the one of your mains, and make sure power unit ON/OFF switch is OFF before you connect to mains.



Switching ON/OFF switch to ON

You can take the computer out of its support and hold it in your hand or place it on the table.

Note: When entering the programme, the computer has to be already plugged into the same socket as it will be for knitting. Do not disconnect it between entering the programme and knitting.

When the computer is disconnected from the power supply, or if the current is interrupted in some way, or if the ON/OFF switch is switched OFF, the programme is automatically erased, and you have to re-enter it.

Enter the two or three digit number which you find on the first line of your programme.

In our example on page 8 this number is 80 (the number on black background indicates the "shop size" to which the programme refers and is never entered).

The number will appear in the red light display.

Press Key E when the correct figure appears in the light display.

If a wrong number is displayed because you have entered an incorrect figure, **press Key C to clear the error**. When you get the message ERR alternating with the figure 1 it means you have attempted to enter a figure the computer will not accept. You can clear this also by pressing Key C. Continue in this way, remembering to press Key E after each line, for only then will the computer store a figure with which to calculate later.

The zero on the last line must also be entered, followed once more by E. Now the first figure of the row of figures will automatically be displayed once more.

Checking the programme

- Check that the figure in the display corresponds to the first line of your programme.
- Press Key E and the next figure of your programme will be displayed. Compare it with your written programme and continue to check in this way until the whole programme has been run through and you get the acoustic signal.

What to do when you discover errors on checking the programme

1. You have entered a wrong figure:

Press Key C to clear the figure, enter the correct one, then press Key E so that the computer will store it. Continue checking.

2. You have forgotten to enter a figure:

Press Key 1 with the symbol for "inserting a figure". Enter the figure you have forgotten and then press Key E. Continue checking.
Should you have forgotten more than one figure, proceed in the same way, i.e. before each figure press Key 1, after each figure press Key E.

3. You have entered one figure too many:

Press Key O to clear this figure.


Correcting the programme while you knit

If you have the impression that the computer is giving you information which cannot be right, or if it suddenly does not display anything, you can check the programme again even during your knitting.

- Press Key E.

The first figure of the programme is displayed. By repeatedly pressing Key E you can run through the whole programme and correct it as described above for the first check.

Knitting with the computer



When knitting with the computer make sure that each time you knit a row the magnet located on the back lock passes in front of the computer, otherwise it will not register this row.

After checking the programme you will hear an acoustic signal and your first knitting instruction will appear in the display.

The acoustic signal always sounds when you have to do something other than straight knitting.

The computer can give you the following knitting instructions:

Figures with a PLUS or MINUS sign always denote stitches

Displayed indications for stitches always refer to the front bed needles only, i.e. in double bed knitting the stitches on the back bed have to be correspondingly increased or decreased as for the stitches of the front bed. If not all needles are knitting any empty needles in between have to be counted as well.




+ (plus) at the beginning of the work means casting on
The number of stitches (i.e. the width of knitting on the front needle bed) which have to be cast on, appears alternately with the figure 1.

(Example: + 128 means: cast on over a width of 128 needles on the front bed)

Should a figure that is higher than 179 appear in this place, it means you cannot achieve the correct width, as required for this garment, with your test square. To achieve a wider test square, either increase the stitch size, choose a different pattern or a different yarn.


Knitting with the computer



+ (plus) during knitting means increasing stitches i. e. always on the side of the knitting where the position indicator lights up and where the lock is.

(Example: + 1 means increase 1 stitch)


If the increases have to be made on the opposite side of the lock, this will be pointed out specially in the garment descriptions.



- (minus) means decreasing stitches on side of the knitting where the position indicator lights up and where the lock is.

(Example: - 3 means decrease 3 stitches)

Figures without a PLUS or MINUS sign always refer to rows which still have to be knitted




The computer counts backwards the rows that still have to be knitted before the next acoustic signal calling your attention to the next knitting instruction.

(Example: 12 means you still have 12 rows to knit before the computer gives you the next instructions)


Flashing figures indicate knitting instructions

These flashing figures which sometimes appear on their own, sometimes alternating with previously mentioned figures, indicate a knitting process which will always be found in the description to the garment.

Some of these figures always have the same, fixed meaning:



1 = Cast on. This figure flashes alternately with the figure denoting the number of stitches to be cast on. (This type of cast on is indicated in the garment description.)



2 = Transition from border (welts, bands, etc.) to main knitting. Whether any stitches have to be transferred and how the lock setting has to be altered here, is indicated in the corresponding garment description.

Knitting with the computer

3

3 = Dividing the work. The piece of knitting is always divided exactly at the centre by placing the stitches of the left half on to deckercombs or, depending on the stitch pattern, by putting the corresponding needles out of working position with the aid of the pushers.
The right half is always worked first.

4

4 = The first half of the neck opening has been knitted, the second half has still to be knitted.

When the figure 4 appears in the display, the computer is automatically in rest position indicated by short, repetitive acoustic signals. You can now unhurridly put the stitches of the second half back on the needles of the machine, set the lock correctly, without fear that the computer might mistakenly continue to count.

To continue knitting, press Key GO

5

5 = The part is finished. Cast off the remaining stitches or, depending on the instructions, finish with contrast yarn. When the message 5 appears, the computer is automatically in rest position.

Auxiliary Keys used during knitting

GO

9

GO

9



6

If the same part is to be repeated, press Key GO, and the computer will again display the beginning of the knitting.

If the same part is to be repeated with reversed shapings, (e.g. the front part of a jacket), press Key GO, then Key 6 with the symbol for "mirroring".

Knitting with the computer



2

STOP

8



5



3

Key 2 = Knitted rows

For as long as you press this key the display will show the number of rows that have been knitted so far.

Key 8 STOP = Computer in rest position

Always press this key when there is any possibility of the lock passing in front of the computer and working it when you do not wish to do so, e.g. when rows have to be undone. The rest position is denoted by short, repetitive signals.

To continue knitting press Key GO

Key 5 = Undoing knitted rows

If you have to undo some rows press this key when you have finished, enter the number of rows you have unravelled and then press Key E. The computer now moves back in the programme by as many rows as you have entered.

If the word ERR is displayed, alternating with the figure 2 you have entered more rows than you have actually knitted so far. Press Key C and enter the correct number of rows.

Remember, if you pressed Key STOP before undoing the rows you now have to press Key GO before Key 5.

Key 3 = 1 row forward

If you press this key the programme advances by one row, just as if you had actually knitted one row. You can use Key 3 e.g. to get to the correct place in the programme if you have forgotten to press Key GO.

Programming a new part

Before a new programme is entered the old one has to be cleared first, by switching off the computer, i.e. switching ON/OFF switch to OFF.

Switch ON/OFF switch to ON again and enter programme as described above.

ERR 1

Means you have entered a figure the computer cannot accept.
Press Key C and enter the correct figure.

ERR 2

Means you have first pressed Key 5 = rolling back programme for unravelling rows, and then entered a figure which is higher than the rows you have already knitted.
Press Key C and enter the correct figure.

ERR 3

This indication is displayed instead of the message "cast on", and means you have reduced a measurement which can only be increased.
Press Key C and then Key E. The first figure of the programme now appears.
Now check the programme once more and replace the wrong figure with the correct one as described on page 11.

Knitting with the computer

Interruption while knitting



4

Should you not be able to finish a piece of knitting the same day, you can leave the computer switched on overnight. If you want to switch it off, however, first check how many rows you have already knitted by pressing **Key 2 = knitted rows**. Make a note of it, and only then switch to OFF. To continue knitting, you have to re-enter the programme as already described.

If after checking, the symbol for casting on appears, press **Key 4 >>> = fast forward**, enter the row number where you interrupted your knitting, and which is also shown on your row counter. Press Key E and the computer will move forward to the place in the programme where you interrupted.

Note: In order that you may always find the place you are looking for in the programme, the row counter on your machine must always be set to zero at the beginning of each piece of knitting.





Choosing your garment

On the following pages you will find the illustrations to the 42 garments that can be knitted with the programmes in this Instruction Book. Choose the pattern you like. As far as colours, stitch patterns and yarns are concerned, the illustrated garments are just some ideas. **You can of course knit each garment in this book with a different stitch pattern.** In addition to the stitch patterns proposed in this book you will find a selection of another 200 stitch patterns in our Stitch Pattern Book.

And why not use the same programme more than once?

The six sweaters illustrated on the page opposite have all been knitted with the same programme no. 8 for a classic sweater with V-neck, and yet look completely different.

Let your imagination run free now that the FORM COMPUTER has freed you from all those tedious calculations.





1

2

3

A color photograph of two young women posing together outdoors. They are both wearing textured, ribbed-knit cardigans. The woman on the left has blonde hair and is smiling, her right arm is around the other woman's shoulder. The woman on the right has dark brown hair pulled back and is also smiling, holding a pair of orange-tinted sunglasses against her shoulder. They are standing in front of large palm fronds against a blue sky.

5

4


6



7

8

9



10

12

11

14




13



15

16





17

18

1

20

19

22

21



A fashion catalog page featuring two women modeling autumnal attire. The woman on the left is laughing joyfully, wearing a brown ribbed turtleneck sweater over a dark brown corduroy jacket with a belt and a large gold button. She also wears brown corduroy pants and yellow drop earrings. The number 23 is printed at the bottom left. The woman on the right is smiling, wearing a brown wide-brimmed hat and a brown and black plaid coat over a brown ribbed turtleneck sweater. She holds a small black clutch bag. The number 24 is printed next to her. Both women are surrounded by large green palm fronds.

23

24

25



26



27

28

27

28



29




30



31


32



33



34



35

36


38

3

39




40





41



42


Practical tips

Under the heading "**Flashing figures**" you will find in the following descriptions short knitting instructions. As they always refer to the same procedures they are kept short giving just the key-words. The main ones are described in detail in the following to enable you to refer back to them whenever necessary.

Flashing figure 1: Cast on with contrast yarn

Contrast yarn is very often used to cast on if the cast on edge is sewn to another part, as in the case of a hem or a border, a yoke or some other piece of knitting.

As a contrast yarn, it is advisable to use a remainder of some yarn which has about the same thickness as the main yarn that you are going to use for your knitting, but it should be of a contrasting colour to make the stitches stand out.



- **Enter the programme**, as described on page 10.
- **Press Key STOP** when flashing figure 1 for casting on appears.
- **With contrast yarn cast on over the indicated number of needles.**
The type of cast on depends on the pattern which follows. You will find the instructions in the garment description. When casting on with contrast yarn, always use the simplest cast on as it will be unravelled later on, i.e. for single-bed knitting make a simple cast on without pushers, for double-bed knitting cast on with racking.
- **Knit 10 to 12 rows with contrast yarn.**
Should you notice that you have forgotten to press Key STOP while you were knitting with contrast yarn, first press Key 2∇ = knitted rows to see how many rows you have knitted. Then press Key $5 \triangleleft$ = unravelling rows. Enter the number of the already knitted rows, and then press Key E. Your programme now goes back to the beginning with flashing figure 1 appearing for cast on.
- **Bring main yarn into the lock.**
- **Set row counter to zero.**
- **Press Key GO** and knit according to the indications given by the FORM COMPUTER.
Should you have forgotten to press Key GO, check on your row counter how many rows you have already knitted, press Key GO and then as many times Key $3 \triangleright$ = 1 row forward, as the number of rows you have knitted.

Practical tips

Flashing figure 5: A few rows with contrast yarn, release

A piece of knitting is finished in contrast yarn, if the piece has to be attached somewhere stitch by stitch using backstitch, e.g. when attaching a neckband.

- Since the computer is in Rest Position when figures 4 or 5 flash, you can bring the contrast yarn into the lock and knit 10 to 12 rows.
- To release the stitches, move the empty lock twice across the needles.


Unravelling the contrast yarn

Before unravelling the contrast yarn, the piece of knitting must be pressed. In the case of a stitch pattern that must not be pressed, press only the rows knitted in contrast yarn. This will prevent the stitches from running while you sew.

Sewing when knitting with contrast yarn


If you have knitted with contrast yarn, make sure that when you are sewing you catch every loose stitch.

To be sure that no stitch runs while you sew, only unravel the contrast yarn to the last or last but one row before the main yarn, and unravel the rows while your are sewing.




Making a hem

Stitch by stitch sew open row of stitches, always picking up two stitches at a time and unravelling the contrast yarn stitch by stitch.



Back stitching, stitch by stitch

Enter into the open stitch at right of the stitch sewn last and emerge from the open stitch at left of it, unravelling contrast yarn stitch by stitch.



The graft stitch

With right side of the knitting facing you, form the missing row of stitches.

Practical tips

Flashing figure 3: Divide work, continue to knit at right

This indication usually appears at the neck opening. **It means that the knitting must be divided exactly in the middle.** To divide the work there are various methods, depending on the stitch pattern and the material:

Dividing the work with pushers

This method can be used only for stocking stitch or fairisle with lock setting BX or HX.

- When knitting in stocking stitch, bring for each needle of the right half the corresponding pusher into Working Position.
- Lock BX without arrow key for knitting the right shoulder.
- When knitting in fairisle with lock setting BX or HX, put all pushers of the left half into the blocking rail.
- Make note of pusher and punchcard positions when knitting with the DECO in order to keep the stitch pattern correct for knitting the second half.
- Continue to knit at right with the same lock setting as so far.

With this method there is a danger that the yarn of the last row knitted on the left half may get worn by constantly moving the lock over it. This can be avoided by knitting one or two rows with contrast yarn by hand over the stitches of the left half when dividing the work.

Dividing the work with deckercombs

With complicated stitch patterns, thickish yarn, or if you want to protect the material, it is advisable to use this method. If you don't have enough deckercombs with your machine these are available as special accessory.

Place the stitches of the left half on to the deckercombs.

In the case of double-bed knitting, place the stitches of the front and the back bed on to separate deckercombs.

Before you continue to knit slide the deckercombs down between the two beds.

Make a note of pusher and punchcard positions in order to keep the stitch pattern correct when knitting the second half.

(Depending on the stitch pattern, it may sometimes be better to divide the knitting 2 rows later, e.g. with fairisle where the first 2 rows were knitted in main colour, but the 2 rows trimming colour have to be knitted yet).

Practical tips

Various neckbands and polo neck collar

With each garment there is also the programme used for knitting the neckband or the collar.

If however you decide to knit the garment in a different stitch pattern or with a different yarn, it may be that the suggested neckband is no longer quite suitable. Or maybe you simply prefer a narrow neckband to the collar.

In each case you can knit your neckband with one of the programmes below.


Measuring the neck opening

Before you knit your neckband or collar, you must first finish the front and back parts. Press the parts if required and join the shoulder seams. Now you can measure the neck opening.

Test square for neckband or collar

It is important to knit a test square 40 stitches by 40 rows also for the neckband or collar as described on page 6. **In the case of ribs (e.g. 1:1 rib or 2:2 rib) the test square must be stretched sideways when measuring it**, so that the neckband or collar fits closely afterwards.

Neckband or collar knitted straight



This programme can be used for all neckbands and collars which cannot be knitted tubular, and which do not have any edge increases or decreases. For example: Garments 7, 12, 21, 22, 27, 28, 30.

This programme can also be used for V-neck bands if at the end you fold the two corners to the inside and neaten the mitre in the centre.

Example: Garments 3, 9, 11.

- Enter the measurements of your test square into the programme.
- Enter the measurement in centimetres of your neckband twice at the place indicated.
- Determine the height of your neckband or collar by entering the appropriate measurement in cm at the place indicated.
- Enter the programme into the FORM COMPUTER as described on page 10.

Practical tips

80	
160	
	mm 40 R
	mm 40 sts
75	
30	
	38
	75
	30
	6
	6
0	cm height of band

Flashing figures:

- 1 For all double-bed knitting tubular cast on, as it can be used as a neat edge for the neckband or collar.
- 5 A few rows with contrast yarn, release.
Sewing on is made easier if at flashing figure 5 you first transfer all stitches to the front bed and knit an additional two rows with the main yarn, not forgetting to increase the stitch size accordingly. Only then knit a few rows with contrast yarn and release.


To make up:

Press band or at least the contrast yarn. Sew band in position on the outside of neck opening, st by st, backstitching through the open loops and unravelling contrast yarn.

Join ends of band.

In the case of a neckband for a V-neck opening begin sewing at the centre front point. At the end fold the two corners of the band to the inside and neaten the mitre in the centre so that the stitches on either side are symmetrical. When joining the ends of a polo neck collar, sew the first 5 cms of the seam on the inside, then the rest on the outside. This will prevent the seam from showing when the collar is folded in half to the outside.

Neckband or polo neck collar knitted tubular



If you want to knit a neckband or collar in stocking stitch it is advisable to knit it tubular as this will save you having to join the ends.

Test square: Remember that for the 40 rows of the test square the row counter is relevant, i.e. when the row counter indicates 40 when knitting tubular, you will see only 20 rows on your piece of knitting.

Flashing figures:

- 1 Press Key STOP. Cast on for tubular using contrast yarn, knit a few rows with contrast yarn.
Bring the main yarn into the lock, press Key GO.
- 5 Knit a few rows with contrast yarn, release.
Pressing the piece of knitting can be made easier if you end with a few rows knitted in contrast yarn tubular and then a few rows with lock back and front N.



To make up:

Press collar or neckband. Start unravelling contrast yarn at one end and attach to outside of neck opening st by st, backstitching through the open loops. Fold in half to inside and attach in the same way, unravel contrast yarn.

80	
160	
	mm 40 R
	mm 40 sts
25	
20	
	38
	25
	20
	6
	6
0	cm height of band

Practical tips

Tubular neckband for V-neck opening



78	mm 40 R
146	mm 40 sts
41	cm neck
30	opening
99	
6	
70	
1	
0	

This band is knitted in stocking stitch, tubular and already correctly shaped for the V-neck opening while knitting.

Examples: Garments 1, 5, 15.

Test square:

Remember that for the 40 rows of the test square the row counter is relevant.

Flashing figures:

- 1 **Press Key STOP.** Using contrast yarn make tubular, closed cast on. Knit a few rows with contrast yarn.
Bring main yarn into the lock, **press Key GO.**
When knitting with the main yarn decrease 1 stitch at left front and back every alternate row.
- 7 **From now on increase 1 stitch at left front and back every alternate row** as follows: Bring 1 empty needle into Working Position, transfer the last stitch on to this needle, place purl stitch loop of this last stitch on to the now empty last but one needle.
5 Knit a few rows with contrast yarn, release.

To make up:

Take band off the machine and press as it is. Then unravel the cast on, and possibly the last few K/K-rows, if any. Fold neckband as shown in the photo. Sew in position first on the outside of the neck opening, st by st, backstitching through the open loops and unravelling contrast yarn, then in the same way to the inside.

Abbreviations

In the following garment descriptions you will find these abbreviations for the stitch patterns:

①	Racking handle down	1②	Racking handle one full turn to the left
④	Racing handle up	3210123	Rack back bed to the extreme right before commencing pattern
⑤	Racking handle in 9 o'clock position	↓	Transfer stitches from back to front
—■—	Black strippers	↑	Transfer stitches from front to back
—□—	Orange (red) strippers	1	U 80 lever position
2 R	Knit 2 rows	col 1	First colour
4 R	Knit 4 rows	col 2	Second colour
1③	Racking handle one full turn to the right	■	With front lock alone
2③	Racking handle two full turns to the right	x	When finished, unravel these stitches

Lady's summery kimono dress

1

Front part

34	38	42
100	100	100
136	136	136
162	170	178
96	103	108
96	103	108
98	98	98
7	7	7
1	1	1
55	55	55
64	64	64
150	158	168
89	95	101
46	47	47
113	116	116
107	107	107
191	191	191
131	133	133
33	33	33
71	71	71
2	2	2
3	3	3
127	127	127
3	3	3
129	130	130
33	33	33
16	16	16
232	232	231
63	63	39
128	130	29
27	29	191
191	191	143
141	143	130
129	130	190
189	190	156
153	156	68
68	68	191
191	191	153
152	153	29
27	29	6
5	6	0
0	0	0



Back

34	38	42
100	100	100
136	136	136
162	170	178
96	103	108
96	103	108
98	98	98
7	7	7
1	1	1
55	55	55
64	64	64
150	158	168
89	95	101
46	47	47
113	116	116
107	107	107
191	191	191
131	133	133
33	33	33
71	71	71
2	2	2
3	3	3
127	127	127
3	3	3
129	130	130
33	33	33
16	16	16
232	232	231
63	63	39
128	130	29
27	29	191
191	191	143
141	143	130
129	130	190
189	190	156
153	156	68
68	68	191
191	191	153
152	153	29
27	29	6
5	6	0
0	0	0

Neckband

78
146
107
74
99
3
67
4
0


mm 40 R
mm 40 sts

cm neck opening

mm 40 R
mm 40 sts
max. hip size

cm hip size
cm total length dress

cm total length dress



Flashing figures:

- Front and back part: closed cast on for tubular.
- Neckband: with contrast yarn closed cast on for tubular. When knitting with the main yarn, decrease 1 stitch at left front and back every alternate row until flashing figure 10.
- Divide work, continue to knit at right.
- End of first shoulder, to knit second shoulder press key GO.
- Front and back part: cast off all remaining stitches.
- Neckband: a few rows with contrast yarn, release.
- Transfer all stitches to front for pattern.
- For the waist transfer every alternate stitch to back bed, empty needles out of Working Position. Lock N/N, St.S 4.
- Transfer all stitches to front for pattern.
- Neckband: increase 1 stitch at left front and back every alternate row to the end.

To make up:

Block and press parts. Join side and shoulder seams. Measure neck opening and knit neckband to match. Backstitch neckband st by st first to the outside of neck opening, then to inside, st by st, backstitching through the open loops and unravelling contrast yarn. Press seams.

Note:

For size 42 the test square for 40 stitches must amount to at least 136 mm. Never increase the hip size beyond the indicated maximum hip size.

Material:


550–620 g medium mercerised cotton yarn (420 m length per 100 g, 132 yds per 1 oz).

Stitch size:

Pattern and stocking stitch = 5, waist = 4.

Pattern:

Tuck stitch with DECO punchcard 19.



Neckband: Stocking stitch, tubular.

Man's shirt style sweater, short sleeves

Front part

48	52	56
87	87	87
166	166	166
126	136	144
96	104	112
96	104	112
195	195	195
7	7	7
6	6	6
38	38	38
126	136	144
96	104	112
31	31	31
61	62	63
232	232	233
7	7	7
2	2	2
161	161	161
153	178	187
179	162	130
146	164	162
7	7	164
34	35	7
72	72	36
160	160	73
7	7	160
34	36	7
161	161	37
178	178	169
145	145	161
146	146	178
5	5	145
0	0	146
		5
		0

mm 40 R
mm 40 sts

mm 40 R border

cm chest

cm total length


Back


48	52	56
87	87	87
166	166	166
126	136	144
96	104	112
96	104	112
195	195	195
7	7	7
6	6	6
38	38	38
126	136	144
96	104	112
31	31	31
61	62	63
232	232	233
7	7	7
2	2	2
161	161	161
153	178	187
179	162	130
146	164	162
7	7	164
34	35	7
72	72	36
160	160	73
7	7	160
34	36	7
161	161	37
178	178	169
145	145	161
146	146	178
5	5	145
0	0	146
		5
		0

mm 40 R
mm 40 sts

mm 40 R border

cm chest

cm total length


Sleeve

48	52	56
87	87	87
166	166	166
82	82	92
34	36	38
34	36	38
195	195	195
7	7	7
2	2	2
38	38	38
90	92	102
38	40	42
13	13	13
29	30	31
102	102	102
5	5	5
153	161	161
138	138	138
191	191	191
152	153	158
143	146	148
0	0	0

mm 40 R
mm 40 sts

mm 40 R border

cm sleeve width

cm sleeve length


Collar

48	52	56
40	40	40
144	144	144

mm 40 R
mm 40 sts


Front band

40
144
50
18
101
7
3
71
1
3
0

mm 40 R
mm 40 sts

cm front band

To make up:

Block and press parts. To ascertain length of front bands, measure along front edges. Then knit one band with and one band without buttonholes. Attach front bands to outside edge of front edges, st by st, backstitching through the open loops and unravelling contrast yarn. At lower edge, place front bands one over the other and sew in position with invisible stitches. Sew collar in position round neck edge as given for front bands. Join side and sleeve seams. Set in sleeves.

Material:


medium mercerised cotton yarn (420 m length per 100 g, 132 yds per 1 oz) 225–280 g brown, 150–200 g yellow. 3 buttons.

Stitch size:

Pattern = 5½, stocking stitch = 5½, 1:1 rib = 2¾.

Pattern:

Two-coloured tuck stitch with DECO punchcard 50.



2 R GX
AX←
2 R GX
AX←

Welt and cuffs: 1:1 rib.

Collar and front bands: Stocking stitch, tubular.

Lady's lacy summer top

3

Front part

34	36	40	44
80	80	80	80
148	148	148	148
132	138	146	154
84	87	93	99
84	87	93	99
195	195	195	195
7	7	7	7
7	7	7	7
38	38	38	38
132	138	146	154
84	87	93	99
34	34	34	34
62	62	63	64
235	236	236	236
7	7	7	7
3	3	3	3
169	169	169	169
153	153	178	178
179	188	188	188
146	129	129	129
7	146	146	146
28	7	7	7
191	27	29	31
146	191	191	191
3	147	148	150
67	3	3	3
191	67	67	67
146	191	191	191
42	146	146	146
0	42	45	47
0	0	0	0

mm 40 R
mm 40 sts

mm 40 R
border

cm bust

cm total length



Back

34	36	40	44
80	80	80	80
148	148	148	148
118	122	130	138
84	87	93	99
84	87	93	99
195	195	195	195
7	7	7	7
7	7	7	7
38	38	38	38
118	122	130	138
84	87	93	99
34	34	34	34
62	62	63	64
234	234	234	235
7	7	7	7
3	3	3	3
153	153	153	153
162	162	179	188
146	155	164	129
7	7	7	164
28	27	27	7
191	191	191	29
146	147	148	191
3	3	3	150
72	72	72	3
185	185	185	72
129	129	129	185
186	186	186	129
129	129	129	186
188	188	188	129
129	129	129	188
137	137	137	129
3	3	3	137
0	0	0	3
0	0	0	0

Sleeve

34	36	40	44
80	80	80	80
148	148	148	148
76	82	88	94
28	30	32	34
28	30	32	34
195	195	195	195
7	7	7	7
2	2	2	2
38	38	38	38
88	94	100	106
32	34	36	38
9	9	9	9
27	27	27	27

mm 40 R
mm 40 sts

mm 40 R
border

cm sleeve width

cm sleeve length



Neckband

103
158
162
64
97
5
0

mm 40 R
mm 40 sts

cm neck opening

Material:



250–300 g medium mercerised cotton yarn, lemon (420 m length per 100 g, 132 yds per 1 oz).

Stitch size:

Lace pattern back = 5, front = 4,
1:1 rib = 2¾.

Pattern:

Lace pattern with DECO punchcard 85 and U70 or U80.



Welt, cuffs and neckband: 1:1 rib.

Flashing figures:

- 1 Tubular cast on for 1:1 rib.
- 2 Transfer all stitches to back bed for pattern.
- 3 Divide work, cont. to knit at right.
- 4 End of first shoulder, to knit second shoulder press key GO.
- 5 Back and front part: cast off all remaining stitches.

Neckband: a few rows with contrast yarn, release.

To make up:

Block and press parts. Join shoulder, side and sleeve seams. Measure neck opening and knit neckband. Sew neckband to neck opening, st by st, back-stitching through the open loops and unravelling contrast yarn. Join point. Set in sleeves.

Front part

34	36	40	44	46	48
100	100	100	100	100	100
406	406	406	406	406	406
60	61	66	70	74	77
3	3	3	3	3	3
3	3	3	3	3	3
195	195	195	195	195	195
7	7	7	7	7	7
6	6	6	6	6	6
38	38	38	38	38	38
60	61	66	70	74	77
84	87	93	99	102	108
24	24	24	24	24	24
59	60	62	63	63	64
235	234	235	235	235	235
7	7	7	7	7	7
1	1	1	1	1	1
161	178	161	177	177	177
153	179	153	169	161	161
162	146	179	162	179	179
155	7	146	146	155	155
7	30	7	7	7	7
28	191	34	37	35	37
191	150	191	191	191	191
150	1	151	149	153	155
1	70	1	1	1	1
71	176	71	72	72	72
168	161	176	184	184	184
161	179	161	131	131	131
153	146	153	161	169	177
162	7	162	153	161	161
137	3	164	145	145	145
7	0	7	155	146	146
4		1	7	7	7
0		0	6	7	8
		0	0	0	0

mm
40 R
mm
40 sts

mm
40 R
border

cm
bust

cm
total
length


Back

34	36	40	44	46	48
100	100	100	100	100	100
150	150	150	150	150	150
120	122	132	138	150	156
3	3	3	3	3	3
3	3	3	3	3	3
195	195	195	195	195	195
7	7	7	7	7	7
6	6	6	6	6	6
38	38	38	38	38	38
120	122	132	138	150	156
84	87	93	99	102	108
24	24	24	24	24	24
59	60	62	63	63	64
235	235	235	235	235	235
7	7	7	7	7	7
1	1	1	1	1	1
161	178	161	177	177	177
153	179	153	169	161	161
162	146	179	162	179	179
155	7	146	146	155	155
7	30	7	7	7	7
28	191	34	37	35	37
191	150	191	191	191	191
150	1	151	149	153	155
1	70	1	1	1	1
71	176	71	72	72	72
168	161	176	184	184	184
161	179	161	131	131	131
153	146	153	161	169	177
162	7	162	153	161	161
137	3	164	145	145	145
7	0	7	155	146	146
4		1	7	7	7
0		0	6	7	8
		0	0	0	0

Sleeve

34	36	40	44	46	48
100	100	100	100	100	100
150	150	150	150	150	150
58	62	66	70	72	74
3	3	3	3	3	3
3	3	3	3	3	3
195	195	195	195	195	195
7	7	7	7	7	7
6	6	6	6	6	6
38	38	38	38	38	38
84	88	96	106	112	118
32	33	36	40	42	44
36	36	36	36	36	36
58	58	59	61	61	62

mm
40 R
mm
40 sts

mm
40 R
border

cm
bust

cm
total
length

**Bands**

75
154
mm 40 R
mm 40 sts
151
58
cm band
101
5
67
1
68
2
0

Material:


330–400 g fairly fine Mohair/Acrylic
(475 m length per 100 g, 149 yds per 1 oz).

Stitch size:

Pattern = 5, 1:1 rib = 2 3/4, K/K = 3,
tubular = 5 1/2.

Pattern:

Single-bed tuck stitch.



2 R N
AX←
2 R N
N

Waist and sleeve bands: 1:1 rib.

Neck and front bands: K/K and tubular.

Flashing figures:

- Front and back part, sleeves: tubular cast on for 1:1 rib.
Front and neck bands: tubular cast on for K/K.
- Transfer all stitches to front for pattern.

3 Divide work, continue to knit at right.

4 End of first shoulder, to knit second shoulder press key GO.

5 Cast off all remaining stitches.

Neck and front bands: a few rows with contrast yarn, release.

7 Buttonhole band: work 6 buttonholes (3–4 stitches across) spread evenly across the band.

Button band: continue to knit.

Neckband: about 5 stitches from right edge work buttonhole as given above.

8 Lock front and back CX, continue to knit tubular.

To make up:

Pin parts out to size and leave to dry under damp cloth. Join shoulder, side and sleeve seams. Measure along jacket front edges and knit one buttonhole band and one button band to match. St by st, backstitch bands to front edges first on the outside, then on the inside, st by st, backstitching through the open loops and unravelling contrast yarn. Measure neck opening and knit neckband. Attach neckband as given for front bands. Set in sleeves.

Front part

34	36	40	44
80 148	80 148	80 148	80 148
120 3 3 195	124 3 3 195	134 3 3 195	142 3 3 195
7 1 38 120 84	7 1 38 124 87	7 1 38 134 93	7 1 38 142 99
32 60	32 60	32 61	32 62
231 5 56 129 7 48 189 165 67 191 145 38 0	231 5 56 129 7 51 189 167 67 191 147 41 0	231 5 56 129 7 51 189 170 67 191 147 41 0	231 5 56 129 7 51 189 174 70 185 131 177 161 162 2 0

mm 40 R
mm 40 sts

mm 40 R
border

cm bust

cm total length



Back

34	36	40	44
80 148	80 148	80 148	80 148
120 3 3 195	124 3 3 195	134 3 3 195	142 3 3 195
7 1 38 120 84	7 1 38 124 87	7 1 38 134 93	7 1 38 142 99
32 60	32 60	32 61	32 62
231 5 56 129 7 48 189 165 67 191 145 38 0	231 5 56 129 7 51 189 167 70 185 131 177 161 162 2 0	231 5 56 129 7 51 189 170 70 185 133 177 161 162 2 0	231 5 56 129 7 51 189 174 70 185 133 177 161 162 2 0

mm 40 R
mm 40 sts

mm 40 R
border

cm bust

cm total length



Neckband

78
146

mm 40 R
mm 40 sts

cm neck opening

Sleeve band

80
160

mm 40 R
mm 40 sts

75
60

cm opening

Material:


fairly fine Mohair/Acrylic (475 m length per 100 g, 149 yds per 1 oz), 80–110 g yellow and 70–90 g pale yellow.

Stitch size:

Pattern back = 4½, front = 5½,
stocking stitch = 5½.

Pattern:

Summer fairisle acc. to diagram with DECO punchcard 55.



N
HX←
2 R pale yellow
2 R yellow

When you have finished, release and unravel all stitches knitted on the front bed.

When decreasing, release the stitches on front bed.

Waist, sleeve and neck bands:
stocking stitch tubular.

Flashing figures:

- 1 Front and back part: closed cast on for tubular. Knit tubular.
Sleeve and neck bands: begin with contrast yarn, closed cast on for tubular. When knitting with main yarn, decrease 1 stitch at left front and back every alternate row until flashing figure 7.
- 2 Transfer all stitches to back for pattern.
- 3 Divide work, cont. to knit at right.
- 4 End of first shoulder, to knit second shoulder press key GO.
- 5 Front, back part: cast off all stitches of back bed, unravel stitches of front bed.
Sleeve and neck bands: a few rows with contrast yarn, release.
- 7 On neckband increase 1 stitch at left front and back every alternate row until the end.

To make up:

Block and press parts lightly. Ensure that all stitches of the front bed are unravelled. Join shoulder and side seams. Measure neck opening and armhole, knit bands, and backstitch, st by st, first to outside, then to inside, st by st, backstitching through the open loops and unravelling contrast yarn.

Skirt part

102	
416	
	mm 40 R
	mm 40 sts
170	
68	
	skirt length
105	
7	
7	
255	
128	
201	
129	
191	
201	
1	
0	



For sizes **34 + 36** knit skirt parts 10 times.

For sizes **38 + 40** knit skirt parts 11 times.

For sizes **42 + 44** knit skirt parts 12 times.

Note:

For a skirt length of 68 cm, the test square for 40 sts must amount to at least 152 mm.

Material:

280–350 g fairly fine Mohair/Acrylic (475 m length per 100 g, 149 yds per 1 oz), 1 length waist elastic.

Stitch size:

front = 6, back = 4 $\frac{3}{4}$.

Pattern:

Stocking stitch with graduations (short rows). For hem border: opposite the last 5 stitches bring 5 needles into Working Position at right on back bed. Handle down, lock back CX.

Waistband:

Stocking stitch, tubular. Begin with contrast yarn. With 9 needles on each bed knit tubular waist band acc. to required length (i.e. waist size + at least 10 cm), a few rows with contrast yarn, release. Press.

Flashing figures:

- 1 With contrast yarn cast on for stocking stitch.
- 6 To make graduations, bring all pushers into Working Position at front. Lock BX. Make the decreases as follows: when the lock is at right, bring the indicated number of pushers into Rest Position at left.
- 5 All pushers in Rest Position, lock front N. Press key GO, and repeat the programme as often as is necessary for your size. After the last repeat knit 2 more rows with main yarn. End with a few rows contrast yarn, release.

To make up:

Block and press skirt. Graft together beginning and end, unravel contrast yarn. Graft together waistband, insert waist elastic, unravel contrast yarn. Using green tool crochet waistband to skirt top.

Man's sweater, round neckline

7

Front part

42	44	48	52	56
91 154	91 154	91 154	91 154	91 154
126 86 86 195	130 90 90 195	136 96 96 195	146 104 104 195	156 112 112 195
7 8 38 126 86	7 8 38 130 90	7 8 38 136 96	7 8 38 146 104	7 8 38 156 112
33 63	33 64	33 66	33 67	33 68
235 7 2 169 153 145 146 7 25 191 150 128 71 177 161 178 162 137 7 8 0	235 7 2 169 153 145 146 7 28 191 153 128 71 177 161 178 162 137 7 8 0	235 7 2 169 153 145 146 7 31 191 155 128 71 177 161 178 162 137 7 8 0	235 7 2 169 153 146 146 7 33 191 157 128 71 177 161 178 162 137 7 8 0	235 7 2 169 153 146 146 7 35 191 153 128 71 177 161 178 162 137 7 8 0

mm 40 R
mm 40 sts

mm 40 R
border

cm chest

cm total length



Back


42	44	48	52	56
91 154	91 154	91 154	91 154	91 154
122 86 86 195	126 90 90 195	130 96 96 195	142 104 104 195	152 112 112 195
7 8 38 122 86	7 8 38 126 90	7 8 38 130 96	7 8 38 142 104	7 8 38 152 112
33 62	33 63	33 65	33 66	33 67
234 7 2 169 153 146 146 7 25 191 150 128 71 185 131 169 153 145 137 2 0	234 7 2 169 153 146 146 7 28 191 153 128 71 185 131 169 153 145 137 2 0	234 7 2 169 153 146 146 7 31 191 155 128 71 185 131 169 153 145 137 2 0	235 7 2 169 153 146 146 7 33 191 157 128 71 185 131 169 153 145 137 2 0	235 7 2 169 153 146 146 7 35 191 153 128 71 185 131 169 153 145 137 2 0

mm 40 R
mm 40 sts

mm 40 R
border

cm chest

cm total length



Sleeve

42	44	48	52	56
91 154	91 154	91 154	91 154	91 154
62 24 24 195	68 26 26 195	72 28 28 195	78 30 30 195	84 32 32 195
7 8 38 88 34	7 8 38 94 36	7 8 38 98 40	7 8 38 104 42	7 8 38 110 42
40 63	40 63	40 64	40 64	40 64
103 7 153 191 149 21 153 0	105 7 153 145 191 147 19 153 0	104 7 153 145 191 150 22 161 0	104 7 153 145 191 153 25 148 0	106 7 161 153 145 191 20 145 178 0

mm 40 R
mm 40 sts

mm 40 R
border

cm sleeve width

cm sleeve length



Material:


fairly fine Mohair/Acrylic (475 m length per 100 g, 149 yds per 1 oz), 390–430 g green, 130–160 g pale green, 110–130 g yellow, 50–70 g brown.

Stitch size:

Fairisle = 5, 2:2 rib = 4½.

Pattern:

Fairisle with DECO punchcard 37.



BX↔
BX↔

Colour sequence:

Rows acc. to right-hand window of card reader.

Main colour: green

0–20 brown

20–52 yellow

52–96 pale green

96–20 brown

20–44 yellow

44–76 pale green

repeat

Borders and neckband: 2:2 rib.

Flashing figures:

1 Front, back part and sleeves: tubular cast on for 2:2 rib over the width of the indicated needles.

Neckband: with contrast yarn tubular cast on for 2:2 rib.

2 Bring all needles into Working Position. Knit the first 2 rows with lock front and back CX, then set lock for the pattern.

Neckband

80
160
75
30
98
7
8
0

mm 40 R

mm 40 sts

cm neck opening

To make up:

Block and press parts. Join shoulder seams. Measure neck opening, knit neckband and join in a ring. St by st, backstitch neckband first to outside of neck opening, then to inside, st by st, backstitching through the open loops and unravelling contrast yarn. Join side and sleeve seams. Set in sleeves.

Lady's V-neck sweater

Front part

34	38	42	46	50	54
48	48	48	48	48	48
145	145	145	145	145	145
120	126	136	144	162	178
44	46	50	53	59	65
44	46	50	53	59	65
195	195	195	195	195	195
7	7	7	7	7	7
26	26	26	26	26	26
38	38	38	38	38	38
120	126	136	144	162	178
84	90	96	102	114	128
30	30	30	30	31	31
64	64	66	68	71	73
226	226	226	226	226	226
7	7	7	7	7	7
13	13	13	13	13	13
69	69	69	69	69	69
191	191	191	191	191	191
138	138	141	142	144	145
83	91	91	101	109	109
7	7	7	7	7	7
5	5	5	5	5	5
105	104	104	104	105	107
179	190	190	190	179	179
164	133	133	133	162	188
167	164	164	164	182	129
1	7	7	7	158	182
7	66	66	76	7	167
53	191	191	191	77	1
191	151	153	156	191	7
150	5	5	5	160	80
5	0	0	0	5	191
0				0	162
					5
					0

Back

34	38	42	46	50	54
48	48	48	48	48	48
145	145	145	145	145	145
120	126	136	144	162	178
44	46	50	53	59	65
44	46	50	53	59	65
195	195	195	195	195	195
7	7	7	7	7	7
26	26	26	26	26	26
38	38	38	38	38	38
120	126	136	144	162	178
84	90	96	102	114	128
30	30	30	30	31	31
64	64	66	68	71	73
226	226	226	226	226	226
7	7	7	7	7	7
13	13	13	13	13	13
69	69	69	69	69	69
191	191	191	191	191	191
138	138	141	142	144	145
83	91	91	101	109	109
7	7	7	7	7	7
5	5	5	5	5	5
105	104	104	104	105	107
179	190	190	190	179	179
164	133	133	133	162	188
167	164	164	164	182	129
1	7	7	7	158	182
7	66	66	76	7	167
53	191	191	191	77	1
191	151	153	156	191	7
150	5	5	5	160	80
5	0	0	0	5	191
0				0	162
					5
					0

Sleeve


34	38	42	46	50	54
48	48	48	48	48	48
145	145	145	145	145	145
64	64	68	68	72	72
24	24	25	25	26	26
24	24	25	25	26	26
195	195	195	195	195	195
7	7	7	7	7	7
18	18	18	18	18	18
38	38	38	38	38	38
96	98	106	110	112	116
35	36	39	40	41	42
35	36	38	38	39	39
57	58	61	62	64	65
107	108	107	108	108	109
7	7	7	7	7	7
10	10	10	10	10	10
170	170	170	170	170	170
154	162	162	162	162	154
164	154	180	182	180	182
191	146	191	191	191	191
135	191	136	137	138	140
27	136	29	33	40	35
164	28	158	158	158	167
154	146	162	146	146	1
170	154	170	162	162	146
0	162	0	170	0	154
					0


Neckband

80
160
75
30
98
7
1
0

mm 40 R
mm 40 sts
cm neck opening

Pattern:
Fairisle with DECO punchcard 48b.



BX↔
BX↔

Flashing figures:

- 1 Tubular cast on for 2:2 rib.
 - 2 Bring all needles into Working Position. Knit the first 2 rows tubular (lock CX/CX), then set lock for pattern.
 - 3 Divide work, continue to knit at right.
 - 4 End of first shoulder, to knit second shoulder press key GO.
 - 5 Front part, back and sleeves: cast off all remaining stitches.
- Neckband: a few rows with contrast yarn, release.

To make up:

Press parts lightly. Join shoulder seams. Measure neck opening. Knit neckband and attach, st by st, backstitching through the open loops and unravelling contrast yarn. Mitre point at centre front and catch down superfluous material. Join sleeve and side seams. Set in sleeves.

Material:

fairly fine Mohair/Acrylic (475 m length per 100 g, 149 yds per 1 oz) 280–350 g green, 80–120 g of each : pale green, salmon, yellow.

Stitch size:

Fairisle = 5, 2:2 rib = 4½.

Waist, sleeve and neck bands: 2:2 rib.

Flared skirt, knitted in three parts

9


Skirt part, knitted three times

34	36	40	44	48	52
48 145	48 145	48 145	48 145	48 145	48 145
124 3 3 3 38 86 89	128 3 3 3 38 88 92	132 3 3 3 38 94 98	138 3 3 38 100 108 104	146 3 3 38 108 122 113	160 3 3 38 122 128
45 65	45 65	47 67	48 68	48 68	48 68
99 191 130 204 0	99 191 130 204 0	99 191 130 204 0	99 191 130 204 0	99 191 130 204 0	99 191 130 204 0

mm 40 R
mm 40 sts

cm hips

cm total length



Material:


fairly fine Mohair/Acrylic (475 m length per 100 g, 149 yds per 1 oz) 240–280 g green, 70–90 g yellow, 40–60 g pale green, 50–70 g of each: dark green, orange, salmon.

Stitch size:

5

Pattern:

Fairisle with DECO punchcard 48.



BX↔
BX↔

Colour sequence:

Rows acc. to right-hand window of card reader.

Main colour: green

Cast on:	dark green
44–08	dark green
08–48	orange
48–80	yellow
80–00	dark green
00–24	orange
24–36	yellow
36–60	dark green
60–80	orange
80–00	salmon
00–20	yellow
20–40	pale green

continue to repeat in salmon, yellow, pale green repeating punchcard 48 b only from 60 to the end.

Waistband:

Tubular, stocking stitch, green.

Begin with contrast yarn, with 8 needles on each bed and St.S 5. Knit tubular waist band to required length (i.e. your waist size plus at least 10 cm). End with a few rows contrast yarn, release. Press.

Flashing figures:

1 Tubular cast on.

5 Cast off remaining stitches.

To make up:

Block and press parts lightly. Insert waist elastic into waist band and graft together ends. Join skirt seams. Crochet waist band to waist edge of skirt. Press seams lightly.


Front part

42	46	50	54
55	55	55	55
436	436	436	436
49	54	60	62
84	92	100	108
84	92	100	108
195	195	195	195
7	7	7	7
15	15	15	15
38	38	38	38
49	54	60	62
84	92	100	108
39	40	41	41
73	75	77	78
235	235	236	236
7	7	7	7
8	8	8	8
161	169	169	169
153	153	161	161
145	145	153	153
155	155	145	145
7	7	155	146
63	67	7	7
191	191	70	73
147	151	191	191
5	5	153	155
69	69	5	5
191	191	69	69
132	132	191	191
73	77	132	133
7	7	81	83
5	5	7	7
0	0	5	5
		0	0

mm 40 R
mm 40 stsmm 40 R
border

cm chest

cm total length


**Back**

42	46	50	54
55	55	55	55
180	180	180	180
104	116	128	130
84	92	100	108
84	92	100	108
195	195	195	195
7	7	7	7
15	15	15	15
38	38	38	38
104	116	128	130
84	92	100	108
39	40	41	41
73	75	77	78
106	107	107	107
7	7	7	7
8	8	8	8
153	161	161	161
162	153	153	153
139	145	162	162
7	146	146	146
63	7	7	7
191	66	70	74
149	191	191	191
5	153	156	158
0	5	5	5
	0	0	0

mm 40 R
mm 40 stsmm 40 R
border

cm chest

cm total length

**Sleeve**

42	46	50	54
55	55	55	55
180	180	180	180
48	54	58	58
22	24	26	26
22	24	26	26
195	195	195	195
7	7	7	7
15	15	15	15
38	38	38	38
80	90	98	100
36	40	44	45
35	35	36	36
59	61	63	64
108	107	109	109
7	7	7	7
8	8	8	8
161	169	169	169
153	153	161	161
146	145	153	153
191	191	145	145
135	142	191	191
34	42	136	136
146	145	43	48
145	153	162	155
153	161	153	145
161	0	161	161
0	169	169	0
	0		0

mm 40 R
mm 40 stsmm 40 R
bordercm sleeve width
cm sleeve length**Material:**

fairly fine Mohair/Acrylic
(475 m length per 100 g, 149 yds per 1 oz)
280–320 g dark green, 180–210 g pale green, 6 buttons.

Stitch size:

Pattern = 5½, K/K = 3½.

Pattern:

AX-pattern acc. to diagram.

Flashing figures:


- 1 Tubular cast on for K/K.
- 2 Transfer stitches for pattern acc. to diagram.
- 5 Front part, back and sleeves: cast off all remaining stitches.
For second front part: after pressing key GO, press key for "mirroring".
Front band: a few rows with contrast yarn, release.

Note: Front band:

The message "+ 1" means that here you have to work a buttonhole over 8 stitches.

To make up:

Block and press parts lightly. Join shoulder, side and sleeve seams. Set in sleeves. Take measurement for front band and knit band accordingly. With right sides facing sew in position along front and back edge. Unravel contrast yarn, and if necessary superfluous rows. Neaten loose stitches. Attach buttons.



Welt and bands: K/K.

90
259

mm 40 R

3

12

3

3

99

7

7

8

38

24

3

3

39

179

179

38

18

3

3

134

179

cm total length

0

Front part

36	38	40
88	88	88
132	132	132
138	144	150
3	3	3
3	3	3
195	195	195
7	7	7
24	24	24
38	38	38
138	144	150
87	90	93
21	21	21
60	61	62
236	236	236
7	7	7
3	3	3
169	169	169
161	161	161
153	153	153
179	179	179
155	164	173
7	7	7
27	30	31
191	191	191
139	141	143
128	128	128
67	67	67
191	191	191
151	151	151
50	54	56
0	0	0

mm 40 R
mm 40 sts

mm 40 R
border

cm bust

cm total length



Back


36	38	40
88	88	88
132	132	132
138	144	150
3	3	3
3	3	3
195	195	195
7	7	7
24	24	24
38	38	38
138	144	150
87	90	93
21	21	21
60	61	62
107	107	108
7	7	7
3	3	3
169	169	169
153	153	153
179	179	188
164	173	129
7	7	164
28	30	7
191	191	32
142	144	191
128	128	147
0	0	128
		0

mm 40 R
mm 40 sts

mm 40 R
border

cm bust

cm total length



Bands

80
160

mm 40 R
mm 40 sts

75
30
cm band

98
7
1
0

Material:


fairly fine Mohair/Acrylic
(475 m length per 100 g, 149 yds per 1 oz)
110–140 g rust, 40–60 g each: dark green, pale green, yellow.

Stitch size:

Tuck stitch = 4½, K/K = 3¾.

Pattern:

4-coloured tuck stitch pattern with DECO punchcard 60.



N
AX←

Colour sequence:

2 R dark green
4 R yellow
2 R dark green
4 R pale green
2 R dark green
4 R rust
repeat

Waist, neck and armhole bands: K/K.

Flashing figures:

- 1 Tubular cast on for K/K.
 - 2 At front all pushers in Working Position. Set lock for pattern.
 - 3 Divide work, continue to knit at right.
 - 4 End of first shoulder, to knit second shoulder press key GO.
 - 5 Front part, back: cast off all remaining stitches.
- Neck and armhole bands: a few rows with contrast yarn, release.

To make up:

Block and press parts lightly. Join shoulder and side seams. Measure neck and armhole openings and knit bands to required length. Sew bands in position round neck and armhole openings, st by st, backstitching through the open loops and unravelling contrast yarn. Mitre points on neck and armhole bands, catching down superfluous material on inside.

Front part


34	36	40	44
87	87	87	87
133	133	133	133
134	142	150	158
84	87	93	99
84	87	93	99
195	195	195	195
7	7	7	7
11	11	11	11
38	38	38	38
134	142	150	158
84	87	93	99
26	26	26	26
61	61	62	63
229	229	229	229
7	7	7	7
2	2	2	2
191	191	191	191
167	171	175	179
47	47	48	52
70	70	70	70
169	169	169	169
189	189	189	189
131	131	131	131
182	182	182	182
7	7	7	7
1	1	1	2
0	0	0	0

mm 40 R
mm 40 sts

mm 40 R
border

cm bust

cm total length

**Back**


34	36	40	44
87	87	87	87
133	133	133	133
134	142	150	158
84	87	93	99
84	87	93	99
195	195	195	195
7	7	7	7
11	11	11	11
38	38	38	38
134	142	150	158
84	87	93	99
26	26	26	26
61	61	62	63
101	101	101	101
7	7	7	7
2	2	2	2
191	191	191	191
169	173	177	181
51	51	52	56
0	0	0	0

mm 40 R
mm 40 sts

mm 40 R
border

cm bust

cm total length

**Sleeve**(knit 2nd sleeve with reversed shapings)


34	36	40	44
87	87	87	87
133	133	133	133
74	74	78	82
24	24	26	28
24	24	26	28
195	195	195	195
7	7	7	7
11	11	11	11
38	38	38	38
110	118	126	134
36	38	41	44
35	35	35	35
56	57	58	59
69	69	69	69
7	7	7	7
2	2	2	2
191	191	191	191
168	172	176	180
51	51	52	56
71	71	71	71
7	7	7	7
2	2	2	2
191	191	191	191
168	172	176	180
47	47	48	52
188	188	188	188
137	137	137	137
0	0	0	0

mm 40 R
mm 40 sts

mm 40 R
border

cm sleeve width

cm sleeve length

**Polo neck**

80
160
75
30
98
7
53
0

mm 40 R
mm 40 sts

cm neck opening

Material:


fairly fine Mohair/Acrylic
(475 m length per 100 g, 149 yds per 1 oz)
170–200 g pale green, 60–80 g each:
dark green, yellow, rust.

Stitch size:

Pattern = 5½, 1:1 rib = 2¾.

Pattern:

Stripes in 4 colours.



2 R pale green
2 R contrast colour
Change contrast colour always after
20 rows as follows: dark green, yellow,
rust.

Welt, cuffs, collar: 1:1 rib.

Flashing figures:

- 1 Tubular cast on for 1:1 rib.
- 2 Transfer all stitches to front bed for pattern.
- 3 Divide work, continue to knit at right.
- 4 End of first shoulder, to knit second shoulder press key GO.
- 5 Front part, back and sleeves: cast off all remaining stitches.
Collar: a few rows contrast yarn, release.

To make up:

Block and press all parts. Sew sleeves with mattress stitch between back and front parts, with shorter edge at the front. Measure neck opening, knit collar and attach to outside of neck opening st by st, backstitching through the open loops and unravelling contrast yarn. Close collar seam. Join sleeve and side seams.

Lady's straight dress with collar

13

Front part

34	38	42	46
40 160	40 160	40 160	40 160
116 89	126 95	134 101	140 107
166 116 84	166 126 90	166 134 96	166 140 102
89 110	90 113	90 114	90 115
72 7 73 184 131 174 182 182 7 16 104 6 184 135 83 191 144	72 7 83 184 133 182 166 7 16 104 6 184 139 93 191 144	72 7 88 184 134 182 166 7 16 104 6 184 139 98 191 146	72 7 91 184 136 182 180 7 19 104 6 184 139 103 191 148
0	0	0	0

mm 40 R
mm 40 sts

cm hips

cm bust

cm total length



Back

34	38	42	46
40 160	40 160	40 160	40 160
116 89	126 95	134 101	140 107
38 116 84	38 126 90	38 134 96	38 140 102
89 110	90 113	90 114	90 115
104 6 184 134 136 7 83 191 144	104 6 184 136 138 7 93 191 146	104 6 184 138 138 7 98 191 147	104 6 184 138 138 7 103 191 149
0	0	0	0

mm 40 R
mm 40 sts

cm hips

cm bust

cm total length



Sleeve

34	38	42	46
40 160	40 160	40 160	40 160
50 20 20 38 90 36 36 41 49	50 20 20 38 100 40 40 43 51	53 21 21 38 105 42 42 44 52	55 22 22 38 110 44 44 44 52
98 7 33 0	98 7 33 0	98 7 33 0	98 7 33 0

mm 40 R
mm 40 sts

cm sleeve length



Collar

80 160	mm 40 R
	mm 40 sts
130 52 52 38 75 30	cm neck opening
13 14 14 98 70	
1 0	

Material:


fairly fine Mohair/Acrylic
(475 m length per 100 g, 149 yds per 1 oz)
350–450 g petrol blue, 280–320 g black,
200–240 g each: pale rust and rust.

Stitch size:

Pattern = 4½, stocking stitch, tubular = 5.

Pattern:

4-coloured fairisle with DECO punch-card 94.



Colour sequence: 2 R petrol blue
2 R pale rust
2 R black
2 R rust

Front band: Stocking stitch, tubular.

Front band

80 160	mm 40 R
	mm 40 sts
75 30	cm band
98 7 1 0	

Flashing figures:

- Front part, back, sleeves and collar: petrol blue, tubular cast on with all needles.
- Neckband: closed cast on for tubular.
- Divide work, continue to knit at right.
- End of first shoulder, to knit second shoulder press key GO.
- Front part, back and sleeves: cast off all remaining stitches.
- Collar and front bands: a few rows contrast yarn, release.
- Continue to knit tubular.

To make up:

Block and press parts. Join shoulder seams. Measure neck opening and knit collar to fit. Backstitch collar st by st first to the outside of neck opening, then to inside, st by st, backstitching through the open loops and unravelling contrast yarn. Measure front slit for front bands. Knit front bands and attach as given for collar. Set in sleeves, then join side and sleeve seams.

Man's jacket with round neckline

Front part

48	52	56
118	118	118
430	430	430
60	64	68
26	28	29
26	28	29
195	195	195
7	7	7
3	3	3
38	38	38
60	64	68
96	104	112
34	35	36
72	73	74
234	234	235
7	7	7
1	1	1
161	161	161
178	178	178
179	179	162
7	7	146
25	26	7
191	191	27
154	153	191
1	1	157
70	70	1
161	161	70
153	153	161
162	162	153
137	137	162
7	7	137
2	3	7
0	0	3
		0

 mm 40 R
mm 40 sts

 mm 40 R
border

cm chest

cm total length


Back


48	52	56
118	118	118
174	174	174
118	126	134
103	111	118
103	111	118
195	195	195
7	7	7
3	3	3
38	38	38
118	126	134
96	104	112
34	35	36
72	73	74
106	106	107
7	7	7
1	1	1
153	161	161
162	153	153
164	179	162
7	7	155
24	27	7
191	191	25
153	153	191
1	1	156
0	0	1
		0

 mm 40 R
mm 40 sts

 mm 40 R
border

cm chest

cm total length


Sleeve

48	52	56
118	118	118
174	174	174
64	70	74
28	30	32
28	30	32
195	195	195
7	7	7
3	3	3
38	38	38
100	104	110
43	45	47
37	37	37
61	61	61
106	106	108
7	7	7
1	1	1
161	169	169
153	161	161
145	153	153
191	191	145
155	153	191
11	13	160
153	161	12
161	169	153
0	0	161
		169
		0

 mm 40 R
mm 40 sts

 mm 40 R
border

cm sleeve width

cm sleeve length


Front band

80	259
3	
16	
3	
3	
99	
7	
2	
8	
38	
28	
3	
3	
47	
60	
98	
7	
14	
0	

cm length band

Neckband

80	117
140	41
102	4
71	
5	
69	
2	
0	

 mm 40 R
mm 40 sts
cm neck opening

Material:


450–500 g fairly fine Mohair/Acrylic
(475 m length per 100 g, 149 yds per 1 oz).

Stitch size:

Pattern back = 5, front = 5½,
'long stitch' = 4, 2:2 rib = 3¼.

Pattern:

Raised pattern with DECO punchcard 88 and U80.



Borders, neckband: 2:2 rib.
Front band: 'long stitch' (lock back N, front CX).

Flashing figures:

- Front part, back and sleeves: tubular cast on for 2:2 rib.
Front bands: tubular cast on with all needles.
Neckband: contrast yarn, tubular cast on for 2:2 rib.
- Transfer all stitches to back bed for pattern.
- Front part, back, sleeves and front bands: cast off all remaining stitches.
Neckband: a few rows with contrast yarn, release.
- 6 needles in from the right edge, work buttonhole.
- As for 7.

Note: Neckband

The message "+ 1" means: Work a buttonhole here over a width of 4 needles.

To make up:

Block and press parts. Measure jacket edge for front bands and knit bands to fit. Attach with mattress stitch. Measure neck opening and knit neckband. Back-stitch first to outside of neck opening, st by st, then to inside, st by st, back-stitching through the open loops and unravelling contrast yarn. Join side and sleeve seams. Set in sleeves.

Front part

36	40	44
78 146	78 146	78 146
178 118 118 38 136 92	178 118 118 38 146 98	178 118 118 38 154 104
58 70	58 72	58 72
99 191 137 32 38 124 87	99 191 137 32 38 132 93	99 191 137 32 38 140 99
19 41	19 42	19 42
234 6 161 153 145 146 155 7 33 191 148 1 69 191 142 40 7 1 0	234 6 161 178 145 155 7 33 191 148 1 69 191 142 42 7 1 0	234 6 161 178 162 155 7 34 191 148 1 69 191 142 43 7 1 0

mm 40 R
mm 40 sts

cm hips

cm skirt length

cm bust

cm length nape
of neck to waist



Back

36	40	44
78 146	78 146	78 146
178 118 118 38 136 92	178 118 118 38 146 98	178 118 118 38 154 104
58 70	58 72	58 72
99 191 137 32 38 124 87	99 191 137 32 38 132 93	99 191 137 32 38 140 99
19 41	19 42	19 42
106 6 161 153 145 146 155 7 32 191 148 1 69 191 142 40 7 1 0	106 6 161 178 145 155 7 32 191 148 1 69 191 142 43 7 1 0	106 6 161 161 153 178 178 145 145 155 7 32 191 148 1 69 191 142 43 7 1 0

mm 40 R
mm 40 sts

cm hips

cm skirt length

cm bust

cm length nape
of neck to waist



Sleeve

36	40	44
78 146	78 146	78 146
60 3 3 98 7 1 55 64 94 34	60 3 3 98 7 1 55 64 102 37	60 3 3 98 7 1 55 64 110 40
35 56	38 59	38 60
106 7 6 161 153 145 191 144 159 145 153 0	106 7 6 161 153 145 191 147 159 145 153 0	106 7 6 161 153 145 191 150 161 145 153 0

mm 40 R
mm 40 sts

cm sleeve width

cm sleeve length



Neckband

78 146
102 74
99 5 69 2 0

mm 40 R
mm 40 sts

cm neck opening

Material:


fairly fine Mohair/Acrylic
(475 m length per 100 g, 149 yds per 1 oz)
340–400 g petrol blue, 70–100 g each:
black, brown, beige.

Stitch size:

5.

Pattern:

4-coloured tuck stitch pattern acc. to diagram.



Sleeve hem and neckband: stocking stitch, tubular.

Flashing figures:

1 Front part and back: contrast yarn, cast on for stocking stitch.
Sleeves: closed cast on for tubular.
Neckband: contrast yarn, closed cast on for tubular. When knitting with the main yarn, until flashing figure 8 always decrease 1 stitch front and back at left every alternate row.

3 Divide work, continue to knit at right.
4 End of first shoulder, to knit second shoulder press key GO.

5 Front part, back and sleeves: cast off all remaining stitches.
Neckband: a few rows with contrast yarn, release.

7 Sleeves: transfer all stitches from back bed to front and set lock for pattern.

8 Neckband: every alternate row at left front and back increase 1 stitch to the end.

To make up:

Block and press parts lightly. Join shoulder seams. Measure neck opening and knit neckband to match. St by st, backstitch to neck opening first on the outside, then to inside, st by st, back-stitching through the open loops and unravelling contrast yarn. Join side and sleeve seams. Set in sleeves. Make hem as required, unravel contrast yarn.

Man's shirt style sweater, long sleeves

Front part

44	48	52	56
136	136	136	136
176	176	176	176
102	106	116	126
45	47	51	55
45	47	51	55
195	195	195	195
7	7	7	7
3	3	3	3
38	38	38	38
108	114	124	132
90	96	104	112
30	31	31	31
64	67	67	67
233	233	233	234
6	6	6	6
161	161	161	169
153	153	153	161
145	145	162	153
146	137	146	145
7	7	7	137
21	21	20	7
188	188	188	22
145	146	147	189
73	73	73	148
136	136	136	73
7	7	7	136
12	12	12	7
185	185	185	12
129	130	130	185
153	153	153	130
145	145	146	153
173	182	182	146
4	4	3	182
0	0	0	5
			0

 mm 40 R
mm 40 sts

 mm 40 R
border

cm chest

cm total length


Back

44	48	52	56
136	136	136	136
176	176	176	176
102	106	116	126
45	47	51	55
45	47	51	55
195	195	195	195
7	7	7	7
3	3	3	3
38	38	38	38
108	114	124	132
90	96	104	112
30	31	31	31
64	67	67	67
233	233	233	234
6	6	6	6
161	161	161	169
153	153	153	161
145	145	162	153
146	137	146	145
7	7	7	137
21	21	20	7
188	188	188	22
145	146	147	189
73	73	73	148
136	136	136	73
7	7	7	136
12	12	12	7
185	185	185	12
129	130	130	185
153	153	153	130
145	145	146	153
173	182	182	146
4	4	3	182
0	0	0	5
			0

Sleeve


44	48	52	56
136	136	136	136
176	176	176	176
52	54	58	62
3	3	3	3
3	3	3	3
195	195	195	195
7	7	7	7
7	7	7	7
38	38	38	38
86	92	96	100
38	40	42	44
33	34	34	34
59	61	61	62
106	107	107	107
6	6	6	6
161	161	161	169
153	153	153	161
145	145	162	145
191	191	191	191
135	135	135	137
135	135	135	137
145	145	145	145
178	153	153	153
161	161	161	161
0	169	169	169
	0	0	0

 mm 40 R
mm 40 sts

 mm 40 R
border

cm sleeve width

cm sleeve length


Material:

fairly fine Mohair/Acrylic
(475 m length per 100 g, 149 yds per 1 oz)
150–200 g black, 70–100 g petrol blue,
50–70 g rust, 50–70 g pale rust, 1 zip
16 cm long.

Stitch size:

Pattern = 5½, 1:1 rib = 3,
stocking stitch = 5½.

Pattern:

4-coloured tuck stitch pattern with
DECO punchcard 30.

Flashing figures:

- Front part, back and sleeves: tubular cast on for 1:1 rib.
Collar and front bands: single-bed cast on with contrast yarn.
- Transfer all stitches to front bed for pattern.
- Divide work, continue to knit at right.
- End of first shoulder, to knit second shoulder press key GO.
- Cast off all remaining stitches.
Collar and front bands: a few rows contrast yarn, release.

To make up:


Block and press parts lightly. Join shoulder seams. Measure neck opening and knit collar. Attach collar to outside of neck opening, st by st, backstitching through the open loops and unravelling contrast yarn. Fold in half to inside and sew in position, unravel contrast yarn. Measure front edges and knit two front bands to match. Attach as given for collar. Join sleeve and side seams. Set in sleeves. Sew zip in position at front.

Collar

136	176
92	40
98	7
20	0

Front band

100	166
60	25
97	4
	0


 GX
AX←

Colour sequence:

2 R petrol blue
2 R black
2 R pale rust
2 R black
2 R rust
2 R black

Waistband and cuffs: 1:1 rib.
Front bands: stocking stitch, tubular.

Lady's coat with stand-up collar

17

Front part (knit two symmetrical parts)

38	44	48	52
72 416	72 416	72 416	72 416
81	84	89	98
33	34	36	38
33	34	36	38
38	38	38	38
61	64	69	78
90	99	108	122
70	74	70	68
118	122	122	122
237	237	236	238
7	7	7	7
49	49	49	49
170	170	170	170
154	154	182	162
164	164	191	154
191	191	128	182
128	128	7	191
7	7	7	128
7	7	52	7
44	44	191	7
191	191	156	53
150	152	5	191
5	5	73	156
72	72	184	5
184	184	131	74
131	131	172	184
162	162	164	131
164	164	175	172
175	183	3	164
3	3	149	191
7	7	7	130
9	7	7	154
0	0	0	154



Back
(knit two symmetrical parts)

38	44	48	52
72	72	72	72
336	336	336	336
150	155	165	178
30	31	33	36
30	31	33	36
38	38	38	38
110	115	125	146
90	99	108	122
70	74	70	68
118	122	122	122
111	111	110	111
7	7	7	7
49	49	49	49
186	186	186	186
129	129	128	131
178	178	190	186
162	162	133	129
154	154	191	178
191	191	135	190
135	135	135	133
135	135	7	180
7	7	53	7
43	43	191	60
191	191	193	191
185	188	5	190
5	5	0	0
0	0		

Sleeve

38	44	48	52
72	72	72	72
160	160	160	160
86	86	90	90
34	34	36	36
34	34	36	36
38	38	38	38
110	110	125	128
44	44	50	51
35	37	37	38
64	66	68	69
110	110	109	109
7	7	7	7
21	21	21	21
170	170	170	170
154	154	162	162
164	164	154	154
159	159	166	166
130	130	191	191
191	191	139	140
132	132	29	31
15	15	166	166
150	150	154	154
164	164	162	162
154	154	170	170
170	170	0	0
0	0		



mm 40 R
mm 40 sts

cm sleeve width

Material:

fairly fine yarn
(530 m length per 100 g, 166 yds per 1 oz)
450–500 g offwhite, 400–500 g brown,
340–400 g olive, 350–400 g ochre.

Stitch size:

Fairisle back = $3\frac{3}{4}$, front = $4\frac{1}{2}$,
stocking stitch = $5\frac{1}{2}$.

Pattern:

4-coloured fairisle with DECO punch-card 93.

Flashing figures:

- Front part, back, sleeves and collar: brown, tubular cast on with all needles. Knit 6 rows tubular.
Front bands: contrast yarn, cast on for half tubular, open at right.
 - Front part, back, sleeves, collar: cast off all remaining stitches.
Front band: a few rows with contrast yarn, release.
 - Collar: tubular, continue to knit in brown.

To make up:

Block and press parts. Join back, side and sleeve seams. Measure neck opening and knit collar accordingly. Should your test square not result in the required width, knit the collar in two parts. Then, st by st, backstitch to outside of neck opening, then to inside, st by st, backstitching through the open loops and unravelling contrast yarn. Measure along front edges of coat and knit front band to match, in half tubular. Attach as given for collar. Join sleeve seams and set in sleeves.

Band

Collar

80
160

mm 40 R
mm 40 sts

75
60

cm band

98
7
1
0

mm 40 R
mm 40 sts

cm neck
opening

Colour sequence: 2 R brown
2 R offwhite
2 R olive
2 R ochre

Front bands: Stocking stitch, tubular.

Front part

42	46	50
51	51	51
411	411	411
60	66	74
23	26	28
23	26	28
195	195	195
7	7	7
16	16	16
106	106	106
7	7	7
26	26	26
71	71	71
1	1	1
55	55	55
71	71	71
2	2	2
55	55	55
65	65	65
3	3	3
38	38	38
60	66	74
84	92	100
22	23	22
75	75	77
233	234	233
3	3	3
182	153	161
166	162	179
150	173	182
7	158	7
57	7	73
191	63	191
146	191	155
5	149	5
70	5	70
176	70	176
182	176	179
183	179	182
133	182	174
7	174	7
10	7	13
0	12	0
	0	

mm 40 R
mm 40 sts

mm 40 R border

cm chest

cm total length

**Back**


42	46	50
51	51	51
155	155	155
118	134	148
46	52	57
46	52	57
195	195	195
7	7	7
16	16	16
106	106	106
7	7	7
26	26	26
71	71	71
1	1	1
55	55	55
71	71	71
2	2	2
55	55	55
65	65	65
3	3	3
38	38	38
60	66	74
84	92	100
234	234	235
7	7	7
8	8	4
153	153	153
155	164	145
148	158	155
7	7	158
68	66	7
191	191	72
151	155	191
5	5	160
69	70	5
184	184	70
130	129	184
155	178	129
158	180	178
2	154	180
0	2	154
	0	2

mm 40 R
mm 40 sts

mm 40 R border

cm chest

cm total length

**Sleeve**

42	46	50
51	51	51
155	155	155
62	66	72
24	26	28
24	26	28
195	195	195
7	7	7
20	20	20
38	38	38
92	102	114
36	40	44
39	40	40
62	64	65
105	106	105
7	7	7
5	5	5
179	145	179
155	191	173
191	132	191
142	132	144
35	191	39
155	141	173
179	33	179
0	182	0
	0	

mm 40 R
mm 40 sts

mm 40 R border

cm sleeve width

cm sleeve length

Collar

80
160
75
30
98
7
58
0

mm 40 R
mm 40 sts

cm neck opening

Pocket band

80
160
75
30
98
7
3
0

mm 40 R
mm 40 sts

cm border

**Material:**


medium yarn (370 m length per 100 g, 116 yds per 1 oz), 650–800 g cream, 400–550 g brown, 1 open-ended zip.

Stitch size:

Fairisle = 6, 2:2 rib = 4, stocking stitch = 6.

Pattern:

Fairisle with DECO punchcard 88.



BX↔
BX←

Pocket

47
160
40
16
16
101
7
13
71
4
63
0

mm 40 R
mm 40 sts

All bands, collar: 2:2 rib.
Pocket: Stocking stitch, tubular.

Flashing figures:

1 Front part, back, sleeves, bands and

collar: tubular cast on for 2:2 rib.

Pockets: closed cast on for tubular.

2 Bring all needles into Working Position. Knit the first 2 rows with lock front and back CX. Then set lock for pattern.

5 Front part, back and sleeves: cast off all remaining stitches.

Bands, collar: a few rows with contrast yarn, release.

Pockets: transfer stitches of back bed to front and cast off together with the stitches of the front bed.

7 On the side where the lock is, continue to knit with only one third of the pushers. Put the remaining pushers into the blocking rail. Make note of position of DECO punchcard.

8 Put all pushers which until now have been in Working Position into the blocking rail, and now bring the others into Working Position. Turn DECO punchcard back to noted down position.

9 Bring all pushers into Working Position and continue to knit in pattern.

10 Pockets: continue to knit, half tubular, open at right.

To make up:

Fit pockets into the slits and attach. Measure pocket slits and knit bands to fit. Sew pocket bands in position on the outside, st by st. Measure neck opening and knit collar to fit. Attach collar on the outside of neck opening, st by st, backstitching through the open loops and unravelling contrast yarn. Catch down on inside. Join side and sleeve seams. Set in sleeves.

Lady's jacket with collar

19

Front part

36	40	44
47	47	47
387	387	387
92	104	110
87	93	99
38	38	38
92	104	110
87	93	99
43	45	45
72	76	77
230	230	230
7	7	7
14	14	14
184	184	184
136	136	136
7	7	7
95	103	108
67	67	67
191	191	191
155	161	161
78	86	91
0	0	0

mm 40 R
mm 40 sts

cm bust

cm total length




Back

36	40	44
47	47	47
131	131	131
144	168	178
87	93	99
38	38	38
144	168	178
87	93	99
43	45	45
72	76	77
102	102	102
7	7	7
14	14	14
184	184	184
136	136	136
7	7	7
95	103	108
67	67	67
0	0	0

mm 40 R
mm 40 sts

cm bust

cm total length



Sleeve

36	40	44
47	47	47
131	131	131
86	86	86
28	28	28
28	28	28
38	38	38
148	158	166
57	58	59
57	58	59
44	47	48
50	53	54
98	98	98
7	7	7
16	16	16
0	0	0

mm 40 R
mm 40 sts



Collar

36	40	44
50	50	50
132	132	132
104	104	104
35	35	35
35	35	35
227	227	227
7	7	7
127	127	127
146	154	159
69	69	69
184	184	184
135	135	136
191	191	191
158	159	158
78	86	91
0	0	0

mm 40 R
mm 40 sts



Material:


1600–2000 g medium yarn
(370 m length per 100 g, 116 yds per 1 oz).

Stitch size:


Pin tuck pattern back = 4½, front = 4,
Pattern collar = 5½.

Pattern:

Pin tuck pattern with DECO
punchcard 76.



Pattern collar.



Flashing figures:

- Front part, back and sleeves: tubular cast on with all needles.
Collar: closed cast on for tubular.
- Collar: divide work, continue to knit at right.
- End of first lapel, to knit second lapel press key GO.
- Cast off all remaining stitches.

To make up:

Block and press parts lightly. Join shoulder seams. Set in sleeves. Join side and sleeve seams. With right sides facing, sew collar in position.

36	38	40	42
88 132	88 132	88 132	88 132
168 104	174 108	178 109	178 109
104	108	109	109
38 144 92	38 150	38 156	38 164
55 75	55 75	55 75	55 75
99 191 133 39 0	99 191 133 39 0	99 191 133 39 0	99 191 133 39 0


mm 40 R

mm 40 sts

max. hip size

cm hips

cm skirt length

**Note:**

For sizes 40 and 42 the test square for 40 stitches must result in at least 132 mm. Never increase the measurements for the hips beyond the maximum hip measurement.

Material:

360–420 g medium yarn
(370 m length per 100, 116 yds per 1 oz).

Stitch size:5^{3/4}.**Pattern:**

Stocking stitch, tubular.

Flashing figures:

- 1 Contrast yarn, closed cast on for tubular.
Note: Decrease with 20-deckercomb.
- 5 Cast off all remaining stitches.

To make up:

Knit waistband with 8 needles on each bed, stocking stitch, tubular (waist size + at least 10 cm), begin and end with contrast yarn. Block and press parts. Insert elastic into waistband, close waistband with graft stitch, unravel contrast yarn. Attach waistband to skirt top. Make hem as required, unravel contrast yarn.

Front part

34	38	40	44
139	139	139	139
165	165	165	165
116	124	128	134
84	90	93	99
84	90	93	99
195	195	195	195
7	7	7	7
2	2	2	2
38	38	38	38
116	124	128	134
84	90	93	99
34	34	34	34
62	63	64	66
229	229	229	229
6	6	6	6
184	184	184	184
131	131	131	131
7	7	7	7
19	20	21	25
70	70	70	70
176	176	176	176
186	186	186	186
129	129	129	129
179	179	179	179
164	164	164	164
5	5	5	5
0	0	0	0

mm 40 R
mm 40 sts

mm 40 R
border

cm bust

cm total length



Back


34	38	40	44
139	139	139	139
165	165	165	165
116	124	128	134
84	90	93	99
84	90	93	99
195	195	195	195
7	7	7	7
2	2	2	2
38	38	38	38
116	124	128	134
84	90	93	99
34	34	34	34
62	63	64	66
229	229	229	229
6	6	6	6
184	184	184	184
131	131	131	131
7	7	7	7
19	20	21	25
70	70	70	70
176	176	176	176
186	186	186	186
129	129	129	129
179	179	179	179
164	164	164	164
5	5	5	5
0	0	0	0

mm 40 R
mm 40 sts

mm 40 R
border

cm bust

cm total length



Sleeve

34	38	40	44
139	139	139	139
165	165	165	165
58	58	58	58
24	24	24	24
24	24	24	24
195	195	195	195
7	7	7	7
2	2	2	2
38	38	38	38
90	94	100	110
37	39	41	45
37	39	41	45
42	42	42	42
56	57	58	59
98	98	98	98
7	7	7	7
2	2	2	2
0	0	0	0

mm 40 R
mm 40 sts

mm 40 R
border

cm sleeve length



Polo neck

103
158
162
64
98
7
28
0

mm 40 R
mm 40 sts

cm neck opening

Material:


medium yarn
(390 m length per 100 g, 122 yds per 1 oz)
360–400 g white, 150–180 g donkey,
190–220 g rust.

Stitch size:

AX-fairisle = 5½, 2:2 rib = 5.

Pattern:

AX-fairisle with DECO punchcard 9.



Colour sequence:

Rows acc. to right-hand window of card reader.

Main colour: white

0–72 donkey

72–64 rust

64–40 donkey

40–72 rust

Collar: AX-fairisle acc. to diagram, but without punchcard.

Colour sequence: 2 R white, 2 R donkey.

Welt and cuffs: 2:2 rib.

Flashing figures:

1 Front part, back and sleeves: tubular cast on for 2:2 rib.

Collar: tubular cast on with all needles for AX-fairisle.

2 Bring all needles into Working Position. Knit the first 2 rows with lock front and back CX. Then set lock for pattern.

3 Divide work, continue to knit at right.

4 End of first shoulder, to knit second shoulder press key GO.

5 Front part, back and sleeves: cast off all remaining stitches.

Collar: 2 rows with lock N/N, white, then a few rows contrast yarn, release.

To make up:

Join shoulder seams. Measure neck opening and knit collar. Backstitch collar to outside of neck opening, st by st, then to inside, st by st, backstitching through the open loops and unravelling contrast yarn. Close collar. Set in sleeves. Join side and sleeve seams.


Front part

42	46	50	54
50	50	50	50
220	220	220	220
86	92	100	108
84	92	100	108
84	92	100	108
195	195	195	195
7	7	7	7
37	37	37	37
38	38	38	38
86	92	100	108
84	92	100	108
42	42	43	43
64	64	65	65
229	229	229	229
7	7	7	7
33	33	33	33
191	191	191	191
150	152	154	157
4	4	4	4
70	71	71	71
152	152	160	168
172	162	172	172
183	146	191	191
5	183	129	129
7	5	9	9
10	7	7	7
0	10	6	6
0	0	0	0

mm 40 R
mm 40 stsmm 40 R
border

cm chest

cm total length




Back

42	46	50	54
50	50	50	50
220	220	220	220
86	92	100	108
84	92	100	108
84	92	100	108
195	195	195	195
7	7	7	7
37	37	37	37
38	38	38	38
86	92	100	108
84	92	100	108
42	42	43	43
64	64	65	65
229	229	229	229
7	7	7	7
33	33	33	33
191	191	191	191
150	152	154	157
4	4	4	4
70	71	71	71
152	152	160	168
172	162	172	172
183	146	191	191
5	183	129	129
7	5	9	9
10	7	7	7
0	10	6	6
0	0	0	0

mm 40 R
mm 40 stsmm 40 R
border

cm chest

cm total length



Sleeve

42	46	50	54
50	50	50	50
220	220	220	220
60	60	60	60
33	33	33	33
33	33	33	33
195	195	195	195
7	7	7	7
37	37	37	37
38	38	38	38
72	76	80	86
40	42	44	46
40	40	40	40
60	61	62	63
98	98	98	98
7	7	7	7
9	9	9	9
0	0	0	0

mm 40 R
mm 40 stsmm 40 R
border

cm sleeve width

cm sleeve length



Polo neck

103
158
162
64
98
7
32
0

mm 40 R

mm 40 sts

cm neck opening

Material:

1050–1200 g medium yarn
(390 m length per 100 g, 122 yds per 1 oz).

Stitch size:

AX-pattern and K/K = 4½.

Pattern:


AX-pattern with DECO punchcard 40.

Flashing figures:

- 1 Tubular cast on for K/K.
- 2 Set lock for pattern.
- 3 Divide work, continue to knit at right.
- 4 End of first shoulder, to knit second shoulder press key GO.
- 5 Front part, back and sleeves: cast off all remaining stitches.
Collar: a few rows with contrast yarn, release.

To make up:

Join shoulder seams. Measure neck opening and knit collar to fit. Attach collar to outside of neck opening, st by st, backstitching through the open loops and unravelling contrast yarn. Close collar. Set in sleeves. Join side and sleeve seams.

N
AX

Border and polo neck: K/K.

Lady's polo neck dress

23

Front part

36	40	44
78	78	78
146	146	146
178	178	178
118	118	118
118	118	118
38	38	38
136	146	154
92	98	104
58	58	58
70	72	72
99	99	99
191	191	191
137	137	137
32	37	37
38	38	38
124	132	140
87	93	99
19	19	18
41	41	41
234	234	234
6	6	6
169	169	169
153	178	178
162	162	179
137	146	146
7	7	7
32	32	33
191	191	191
150	150	150
1	1	1
72	72	72
184	184	184
130	130	130
161	161	161
153	153	153
145	145	145
146	155	164
7	7	7
8	8	8
0	0	0



Polo neck

103
158
162
128
98
7
63
0

mm 40 R
mm 40 sts

cm neck opening

Back

36	40	44
78	78	78
146	146	146
178	178	178
118	118	118
118	118	118
38	38	38
136	146	154
92	98	104
58	58	58
70	72	72
99	99	99
191	191	191
137	137	137
32	37	37
38	38	38
124	132	140
87	93	99
19	19	18
41	41	41
234	234	234
6	6	6
169	169	169
153	178	178
162	162	179
137	146	146
7	7	7
32	32	33
191	191	191
150	150	150
1	1	1
72	72	72
184	184	184
130	130	130
161	161	161
153	153	153
145	145	145
146	155	164
7	7	7
8	8	8
0	0	0

Sleeve

36	40	44
78	78	78
146	146	146
60	60	60
3	3	3
3	3	3
195	195	195
7	7	7
29	29	29
38	38	38
94	102	110
34	37	40
31	34	34
56	59	60
106	106	106
7	7	7
6	6	6
161	161	161
153	153	153
145	145	145
191	191	191
144	147	150
152	152	154
145	145	145
153	153	153
0	0	0

mm 40 R
mm 40 sts

mm 40 R
border

cm sleeve width
cm sleeve length



Note:

The test square for 40 stitches must result in at least 145 mm.

Material:

450 g fairly fine Mohair/Acrylic
(475 m length per 100 g, 149 yds per 1 oz).

Stitch size:

Stocking stitch = 5½, 1:1 rib = 3¼.

Pattern:

Front part, back and sleeves:
stocking stitch.

Collar: stocking stitch, tubular.

Cuffs: 1:1 rib.

Flashing figures:

1 Front and back part: contrast yarn,
cast on for stocking stitch.

Collar: contrast yarn, cast on for
stocking stitch, tubular.

Sleeves: tubular cast on for 1:1 rib.

2 Transfer all stitches to front bed for
stocking stitch.

3 Divide work, continue to knit at right.

4 End of first shoulder, to knit second
shoulder press key GO.

5 Front part, back and sleeves: cast off
all remaining stitches.


Collar: a few rows contrast yarn,
release.

To make up:

Block and press parts. Measure neck
opening and knit collar to fit. Join
shoulder, side and sleeve seams. St by
st, backstitch collar first to outside, then
to inside of neck opening, st by st, back-
stitching through the open loops and
unravelling contrast yarn. Set in sleeves.
Make hem to required length, unravel
contrast yarn.


Front part

36	40	44
87 476	87 476	87 476
40 22 22 194	43 23 23 194	44 24 24 194
4 166 40 87	4 166 43 93	4 166 44 99
34 65	35 66	35 67
68 191 133 62 6 101 7 2 24 7 51 0	68 191 134 63 6 101 7 2 24 7 52 0	68 191 134 64 6 101 7 2 32 7 53 0



Back

36	40	44
87 220	87 220	87 220
80 38 38 194	86 42 42 194	90 44 44 194
4 38 80 87	4 38 86 93	4 38 90 99
34 65	35 66	35 67
101 7 2 24 7 51 0	101 7 2 24 7 52 0	101 7 2 32 7 53 0

**Material:**


fairly fine Mohair/Acrylic
(475 m length per 100 g, 149 yds per 1 oz)
140–160 g black, 90–110 g each red,
brown, rust.

Stitch size:

Pin tuck pattern back = 5 1/4, front = 4,
front band back = 4 3/4, front = 5.


Pattern:

Pin tuck pattern with DECO punchcard
95 and COLOR.

**Colour sequence:**

2 R black
2 R red
2 R brown
2 R rust

Front bands

**Flashing figures:**

- 1 Tubular cast on with all needles.
Front bands: cast on with contrast yarn.
- 2 Set lock for pattern.
- 5 Cast off all remaining stitches.
Front bands: a few rows contrast yarn, release.

To make up:

Join shoulder seams. Measure for front bands and armhole bands, knit bands to required length acc. to diagram. Back-stitch the double-bed side of bands to front edges and armhole edges, then fold in half and sew to inside. Unravel contrast yarn and sew down the open loops. Join side seams.

Front part

34	38	44	48
80	80	80	80
364	364	364	364
100	110	116	126
27	30	31	34
27	30	31	34
38	38	38	38
88	96	102	110
84	90	99	108
83	84	83	83
113	116	117	117
237	238	238	238
7	7	7	7
3	3	3	3
178	186	186	186
170	129	131	131
154	178	178	178
191	162	162	162
133	191	191	191
133	133	133	137
7	133	133	137
31	7	7	7
191	36	38	36
159	191	191	191
1	163	165	167
70	3	3	3
191	71	71	72
139	190	190	191
2	133	133	135
182	191	191	128
7	133	135	191
1	5	135	135
0	7	7	135
3	2	2	7
0	0	0	2
	0	0	0

Collar

34	38	44	48
80	80	80	80
108	108	108	108
166	178	182	184
45	48	49	50
45	48	49	50
38	38	38	38
142	154	158	160
39	42	43	44
14	15	15	15
15	16	16	16
15	16	16	16
99	99	99	99
71	71	71	71
1	1	1	1
3	3	3	3
0	0	0	0

1/2 Back

34	38	44	48
80	80	80	80
364	364	364	364
102	111	117	125
27	30	31	34
27	30	31	34
38	38	38	38
88	97	103	109
84	90	99	108
83	84	83	83
113	116	117	117
108	108	109	110
7	7	7	7
3	3	3	3
178	186	186	186
170	129	131	131
154	178	178	178
191	162	162	162
133	191	191	191
133	133	133	137
7	133	133	137
31	7	7	7
191	36	38	36
159	191	191	191
1	163	165	167
70	3	3	3
191	71	71	72
139	190	190	191
2	133	133	135
182	191	191	128
7	133	135	191
1	5	135	135
0	7	7	135
3	2	2	7
0	0	0	2
	0	0	0

Sleeve

34	38	44	48
80	80	80	80
108	108	108	108
130	140	144	148
35	38	39	40
35	38	39	40
38	38	38	38
150	164	168	172
40	44	45	46
40	40	40	40
58	59	60	60
109	111	111	111
7	7	7	7
3	3	3	3
185	185	185	185
129	131	131	131
177	185	185	185
186	129	129	129
129	177	177	177
191	161	161	161
134	145	162	145
19	191	191	191
188	135	135	136
129	21	21	23
178	188	188	188
0	129	129	129
178	178	178	178
0	0	0	0

Front band

80
160

mm 40 R
mm 40 sts
cm bust
cm total length

cm sleeve width

cm sleeve length



Material:


fairly fine Mohair/Acrylic
(475 m length per 100 g, 149 yds per 1 oz)
550–700 g rust, 600–750 g black.

Stitch size:

Fairisle back = 4½, front = 5½.
Stocking stitch, half tubular = 5½.

Pattern:

Reversible fairisle with DECO punch-card 63.



Front bands: half tubular, open at right.

Flashing figures:

- 1 Tubular cast on in rust with 5 rows tubular.
Front band: closed cast on for half tubular.
- 5 Cast off all remaining stitches.
Collar and front band: a few rows contrast yarn, release.
- 7 Collar: knit tubular to the end.

To make up:

Block and press parts. Join back seam and shoulders. Measure neck opening and knit collar to fit. St by st, backstitch collar to outside of neck opening, then to inside, st by st, backstitching through the open loops and unravelling contrast yarn. Measure along front edges and round collar edges and knit front band in two or three pieces depending on your test square. Join the pieces and backstitch to outer edge first, then to inside, st by st, backstitching through the open loops and unravelling contrast yarn. Join sleeve seams. Set in sleeves.


Front part

36	40	44	50
124	124	124	124
164	164	164	164
120	126	134	154
87	93	99	114
98	98	98	98
7	7	7	7
77	83	81	79
38	38	38	38
120	126	134	154
3	3	3	3
3	3	3	3
36	38	37	37
114	119	119	119
231	231	231	231
6	6	6	6
184	184	184	184
136	135	138	141
7	7	7	7
24	24	27	29
189	189	189	189
146	146	146	153
70	71	71	71
168	176	176	176
161	186	186	186
178	129	129	129
162	178	178	153
137	145	145	162
5	137	146	155
0	5	5	5
	0	0	0

mm 40 R
mm 40 sts

cm hips

cm total length


**Back**

36	40	44	50
124	124	124	124
164	164	164	164
120	126	134	154
87	93	99	114
98	98	98	98
7	7	7	7
77	83	81	79
38	38	38	38
120	126	134	154
3	3	3	3
3	3	3	3
36	38	37	37
114	119	119	119
231	231	231	231
6	6	6	6
184	184	184	184
136	135	138	141
7	7	7	7
24	24	27	29
189	189	189	189
146	146	146	153
70	71	71	71
168	176	176	176
161	186	186	186
178	129	129	129
162	178	178	153
137	145	145	162
5	137	146	155
0	5	5	5
	0	0	0

mm 40 R
mm 40 sts

cm hips

cm total length

**Sleeve**

36	40	44	50
124	124	124	124
164	164	164	164
96	100	102	108
39	41	42	44
39	41	42	44
38	38	38	38
96	100	102	108
39	41	42	44
39	41	42	44
45	47	47	47
56	58	59	59
99	99	99	99
71	71	71	71
1	1	1	1
6	6	6	6
0	0	0	0

mm 40 R
mm 40 sts

cm sleeve length

**Collar**

103
158
162
128
98
7
63
0

mm 40 R
mm 40 sts

cm neck opening

Material:


fairly fine Mohair/Acrylic
(475 m length per 100 g, 149 yds per 1 oz)
410–450 g pale rust, 210–250 g dark rust.

Stitch size:

5½.

Pattern:

Fairisle with DECO punchcard 89.



Sleeves: stocking stitch.
Collar: stocking stitch, tubular.

Flashing figures:

- 1 Single bed cast on with contrast yarn.
Collar: closed cast on for tubular, with contrast yarn.
- 3 Divide work, continue to knit at right.
- 4 End of first shoulder, to knit second shoulder press key GO.
- 5 Front and back part: cast off all remaining stitches.
Sleeves and collar: a few rows contrast yarn, release.
- 7 Sleeves: a few rows contrast yarn, release and return stitches to exactly half the number of needles, i.e. place 2 stitches on each needle. Continue to knit stocking stitch.

To make up:

Block and press parts. Join shoulder seams. Measure neck opening and knit collar to match. St by st, backstitch collar to outside of neck opening, then to inside, st by st, backstitching through the open loops and unravelling contrast yarn. Set in sleeves, st by st, backstitching through the open loops and unravelling contrast yarn. Fold cuffs in half to inside and sew in position. Join sleeve and side seams. Make hem.

Man's sweater with raglan sleeves

27

Front part


48	52	56
77	77	77
129	129	129
156	168	182
96	104	112
96	104	112
195	195	195
7	7	7
20	20	20
38	38	38
156	168	182
96	104	112
31	32	33
71	73	75
229	229	229
7	7	7
3	3	3
191	191	191
172	175	182
59	65	68
70	71	71
177	185	185
153	134	134
179	153	153
182	179	179
7	155	155
3	7	7
0	6	6
	0	0

mm 40 R
mm 40 sts

mm 40 R border

cm chest

cm total length



Back


48	52	56
77	77	77
129	129	129
156	168	182
96	104	112
96	104	112
195	195	195
7	7	7
20	20	20
38	38	38
156	168	182
96	104	112
31	32	33
71	73	75
101	101	101
7	7	7
3	3	3
191	191	191
172	180	187
62	70	73
0	0	0

mm 40 R
mm 40 sts

mm 40 R border

cm chest

cm total length



Sleeve

(knit 2nd sleeve with reversed shapings)

48	52	56
77	77	77
129	129	129
82	88	94
26	28	30
26	28	30
195	195	195
7	7	7
20	20	20
38	38	38
126	126	132
40	40	42
32	32	34
62	64	66

mm 40 R
mm 40 sts

mm 40 R border

cm sleeve width

cm sleeve length



Collar

103	158
162	64
98	
7	
24	
0	

mm 40 R
mm 40 sts

cm neck opening

Material:


fairly fine Mohair/Acrylic
(475 m length per 100 g, 149 yds per 1 oz)
230–270 g black, 60–80 g each: pale rust
and dark rust.

Stitch size:

Pattern = 5 $\frac{1}{2}$, 1:1 rib = 3 $\frac{1}{2}$.

Pattern:

single bed tuck stitch pattern.



Colour sequence:

2 R black
2 R pale rust
2 R black
2 R dark rust

Waist and sleeve bands, polo neck
collar: 1:1 rib.

Flashing figures:

- 1 Tubular cast on for 1:1 rib.
- 2 Transfer all stitches to front for pattern.
- 3 Divide work, continue to knit at right.
- 4 End of first shoulder, to knit second shoulder press key GO.
- 5 Cast off all remaining stitches.
Collar: a few rows contrast yarn, release.

To make up:

Block and press parts. Sew sleeves between front and back parts with shorter raglan edge to the front. Measure neck opening and knit collar. St by st, backstitch collar to outside of neck opening, then to inside, st by st, backstitching through the open loops and unravelling contrast yarn. Join sleeve and side seams.

Lady's sweater with round neckline

Front part

38	42	46
50	50	50
160	160	160
126	136	146
50	54	58
50	54	58
195	195	195
7	7	7
17	17	17
38	38	38
126	136	146
90	96	102
28	28	28
61	62	63
237	236	236
7	7	7
9	9	9
162	186	186
154	129	129
164	178	178
191	162	162
128	158	158
7	7	7
7	61	67
53	191	191
191	149	151
146	9	9
9	71	72
71	184	184
184	130	130
128	178	178
153	167	154
162	2	175
182	7	3
7	26	7
28	0	23
0		0

mm 40 R
mm 40 sts

mm 40 R
border

cm bust

cm total length


Back

38	42	46
50	50	50
160	160	160
110	120	130
44	48	52
44	48	52
195	195	195
7	7	7
17	17	17
38	38	38
110	120	130
90	96	102
28	28	28
61	62	63
234	235	235
7	7	7
9	9	9
154	162	170
164	154	154
158	146	146
7	158	158
59	7	7
191	61	67
146	191	191
9	150	153
69	9	9
184	68	68
131	184	184
161	136	139
179	164	164
4	4	4
0	0	0

mm 40 R
mm 40 sts

mm 40 R
border

cm bust

cm total length


Sleeve

38	42	46
50	50	50
160	160	160
60	62	66
24	25	26
24	25	26
195	195	195
7	7	7
17	17	17
38	38	38
90	100	100
36	40	44
34	34	34
56	57	59
107	108	108
7	7	7
9	9	9
191	170	170
131	154	154
131	146	146
191	191	191
136	139	142
23	29	35
179	146	146
189	180	180
136	162	162
0	170	170
0	0	0

mm 40 R
mm 40 sts

mm 40 R
border

cm bust

cm total length

Collar

103
158
162
64
98
7
17
0

mm 40 R
mm 40 sts

mm 40 R
border


cm neck opening

cm sleeve width

cm sleeve length



The 'long stitch' is knitted at the end of the pattern repeat.



Borders and collar: 2:2 rib.

Flashing figures:

- 1 Tubular cast on for 2:2 rib.
 - 2 Bring empty needles into Working Position. Knit the first 2 rows with lock front and back CX. Then set lock for pattern.
 - 3 Divide work, continue to knit at right.
 - 4 End of first shoulder, to knit second shoulder press key GO.
 - 5 Cast off all remaining stitches.
- Collar: a few rows with contrast yarn, release.

To make up:

Block and press parts. Join shoulder, side and sleeve seams. Measure neck opening and knit collar. Sew collar together, and attach to outside of neck opening, st by st, backstitching through the open loops and unravelling contrast yarn. Set in sleeves.

Material:

medium Mohair/Acrylic (475 m length per 100 g, 149 yds per 1 oz), 30–40 g


colour 6, 60–90 g each of colours 5, 4, 3, 1,

290–340 g colour 2 (colour 1 = lightest shade, colour 6 = darkest shade).

Fairisle back = 5, front = 5½,
2:2 rib = 3¾.

Pattern:

Fairisle 'long stitch' with DECO punch-card 75.


Colour sequence:

16 × {	2 R col. 2	R 64
	2 R col. 1	
8 × {	2 R col. 2	R 96
	2 R col. 3	
8 × {	2 R col. 4	R 128
	2 R col. 3	
8 × {	2 R col. 4	R 160
	2 R col. 5	
16 × {	2 R col. 6	R 224
	2 R col. 5	
8 × {	2 R col. 4	R 256
	2 R col. 5	
8 × {	2 R col. 4	R 288
	2 R col. 3	
8 × {	2 R col. 2	R 320
	2 R col. 3	
16 × {	2 R col. 2	R 384
	2 R col. 1	total

Child's sweater with cross-over collar

29

Front part


110	122	134	146	158
48	48	48	48	48
198	198	198	198	198
68	72	76	80	84
68	72	76	80	84
68	72	76	80	84
195	195	195	195	195
7	7	7	7	7
19	19	19	19	19
38	38	38	38	38
68	72	76	80	84
62	66	70	74	80
18	20	22	24	26
41	44	47	50	53
234	234	234	234	234
7	7	7	7	7
1	1	1	1	1
153	161	153	153	153
162	162	162	162	162
137	137	137	137	137
7	7	7	7	7
43	48	52	56	59
191	191	191	191	191
134	135	137	138	140
1	1	1	1	1
68	68	68	68	68
184	184	184	184	184
134	135	135	136	136
7	7	7	7	7
43	48	52	56	59
0	0	0	0	0

mm 40 R
mm 40 sts

mm 40 R
border

cm bust

cm total length



Back

110	122	134	146	158
48	48	48	48	48
198	198	198	198	198
68	72	76	80	84
68	72	76	80	84
68	72	76	80	84
195	195	195	195	195
7	7	7	7	7
19	19	19	19	19
38	38	38	38	38
68	72	76	80	84
62	66	70	74	80
18	20	22	24	26
41	44	47	50	53
106	106	106	106	106
7	7	7	7	7
1	1	1	1	1
153	153	153	153	153
162	162	162	162	162
137	137	137	137	137
7	7	7	7	7
43	48	52	56	59
191	191	191	191	191
134	135	137	138	140
1	1	1	1	1
68	68	68	68	68
184	184	184	184	184
134	135	135	136	136
7	7	7	7	7
43	48	52	56	59
0	0	0	0	0

Sleeve

110	122	134	146	158
48	48	48	48	48
198	198	198	198	198
36	38	40	42	44
36	38	40	42	44
36	38	40	42	44
195	195	195	195	195
7	7	7	7	7
15	15	15	15	15
38	38	38	38	38
52	54	56	58	60
26	27	28	29	30
24	26	28	30	32
41	44	47	50	53

mm 40 R
mm 40 sts

mm 40 R
border

cm sleeve width

cm sleeve length



Material:


medium yarn (530 m length per 100 g, 166 yds per 1 oz), 240–320 g white, 120–160 g blue, 30–50 g red.

Stitch size:

Pattern = $3\frac{3}{4}$, 2:2 rib = 3.

Pattern:

Fairisle with DECO punchcard 44.



BX↔
BX↔

Colour sequence:

Rows acc. to right-hand window of card reader.

Main colour white

0–16	red
16–08	blue
08–28	red
28–20	blue

Borders, collar: 2:2 rib.

Flashing figures:

- 1 Tubular cast on for 2:2 rib.
- 2 Bring empty needles into Working Position. Knit the first 2 rows with lock front and back CX. Then set lock for pattern.
- 3 Divide work, continue to knit at right.
- 4 End of first shoulder, to knit second shoulder press key GO.
- 5 Cast off all remaining stitches.
Collar: a few rows contrast yarn, release.

To make up:

Block and press parts. Join shoulder, side and sleeve seams. Measure neck opening (without measuring horizontal part at front). Knit collar. Sew collar to neck opening, st by st, backstitching through the open loops and unravelling contrast yarn. Cross collar edges and sew to horizontal part of neck opening. Join side and sleeve seams. Set in sleeves.

Collar

103
158
162
64
98
7
11
0

mm 40 R
mm 40 sts

cm neck opening

Front part

98	104	110	122	134	146	158	164
75	75	75	75	75	75	75	75
230	230	230	230	230	230	230	230
54	56	58	62	66	70	74	76
3	3	3	3	3	3	3	3
3	3	3	3	3	3	3	3
195	195	195	195	195	195	195	195
7	7	7	7	7	7	7	7
8	8	8	8	8	8	8	8
38	38	38	38	38	38	38	38
54	56	58	62	66	70	74	76
58	60	62	66	70	74	80	84
14	16	18	20	22	24	28	32
34	37	40	43	46	50	55	60
232	232	232	232	232	233	233	233
5	5	5	5	5	5	5	5
153	153	153	153	153	153	153	161
145	145	145	145	145	145	145	145
146	146	146	146	146	146	146	146
7	7	7	7	7	7	7	7
18	21	24	26	29	32	34	34
189	189	189	189	189	191	191	191
131	131	132	133	135	136	138	138
70	70	70	70	70	1	1	3
161	161	161	161	161	70	70	70
153	153	153	153	153	161	161	161
145	145	162	162	162	153	153	153
137	146	137	137	137	162	162	162
7	7	7	7	7	146	146	155
5	4	4	4	4	7	7	7
0	0	0	0	0	4	4	4
					0	0	0

Back

98	104	110	122	134	146	158	164
75	75	75	75	75	75	75	75
230	230	230	230	230	230	230	230
54	56	58	62	66	70	74	76
3	3	3	3	3	3	3	3
3	3	3	3	3	3	3	3
195	195	195	195	195	195	195	195
7	7	7	7	7	7	7	7
8	8	8	8	8	8	8	8
38	38	38	38	38	38	38	38
54	56	58	62	66	70	74	76
58	60	62	66	70	74	80	84
cm bust							
cm total length							
mm 40 R border							
mm 40 st							
mm 40 R							


Collar

98	122	158
104	134	164
110	146	

mm 40 R
mm 40 st
cm neck opening

cm bust

cm total length



Material:

390–480 g medium yarn
(460 m length per 100 g, 144 yds per 1 oz).


Stitch size:

Pattern back = 4, front = 5½, 2:2 rib = 4.

Pattern: Racking pattern.



mm 40 R
mm 40 st



mm 40 R
border

Borders, polo neck collar: 2:2 rib.

cm sleeve width
cm sleeve length



12 R EX
AX←

2 R EX
AX←
1× Q

12 R EX
AX←

2 R EX
AX←
1× Q

Flashing figures:

- 1 Tubular cast on for 2:2 rib.
- 2 Transfer stitches acc. to diagram.
- 3 Divide work, continue to knit at right.
- 4 End of first shoulder, to knit second shoulder press key GO.
- 5 Cast off all remaining stitches.
Collar: a few rows contrast yarn, release.

To make up:

Block and press parts. Join side, shoulder and sleeve seams. Measure neck opening and knit collar to fit. Close collar seam and attach to neck opening st by st, backstitching through the open loops and unravelling contrast yarn. Set in sleeves.

98	104	110	122	134	146	158	164
75	75	75	75	75	75	75	75
230	230	230	230	230	230	230	230
28	30	32	32	34	36	38	40
16	17	18	19	20	21	22	23
16	17	18	19	20	21	22	23
195	195	195	195	195	195	195	195
7	7	7	7	7	7	7	7
8	8	8	8	8	8	8	8
38	38	38	38	38	38	38	38
40	42	44	46	48	48	50	52
23	24	25	26	27	28	29	30
20	22	24	26	28	30	34	38
34	37	40	43	46	49	54	59
101	101	101	101	101	101	101	101
5	5	5	5	5	5	5	5
145	145	145	145	145	145	145	153
191	191	191	191	191	191	191	191
134	135	138	136	137	136	137	137
11	14	16	19	21	24	26	29
0	0	0	0	0	0	0	0

Child's jacket with round neckline

31

Front part

110	122	134	146	152
52 416	52 416	52 416	52 416	52 416
38 68 68 195	42 72 72 195	44 76 76 195	46 80 80 195	48 84 84 195
7 18 38 38 60	7 18 38 42 64	7 18 38 44 68	7 18 38 46 73	7 18 38 48 76
20 45	22 48	24 51	25 55	27 58
232 7 1 184 131 7 54 189 139 69 153 162 155 7 6 0	232 7 1 184 131 7 58 189 141 69 153 179 155 7 7 0	232 7 1 184 131 7 70 191 144 69 69 179 146 0	233 7 1 184 131 7 74 191 145 69 69 153 153 179 179 155 129 146 13 0	233 7 1 184 131 7 7 191 146 69 69 153 153 179 179 188 129 146 7 15 0

mm 40 R
mm 40 sts

mm 40 R
border

cm chest

cm total
length



Back


110	122	134	146	152
52 160	52 160	52 160	52 160	52 160
86 68 68 195	90 72 72 195	96 76 76 195	100 80 80 195	106 84 84 195
7 18 38 38 60	7 18 38 42 64	7 18 38 44 68	7 18 38 46 73	7 18 38 48 76
20 45	22 48	24 51	25 55	27 58
104 7 1 184 131 7 54 189 139 0	104 7 1 184 131 7 58 189 141 0	104 7 1 184 131 7 70 191 144 0	105 7 1 184 131 7 74 191 145 1	105 7 1 184 131 7 74 191 146 1

mm 40 R
mm 40 sts

mm 40 R
border

cm chest

cm total
length



Sleeve

110	122	134	146	152
52 160	52 160	52 160	52 160	52 160
46 18 18 195	48 19 19 195	50 20 20 195	52 21 21 195	54 22 22 195
7 14 38 80 32 32 39	7 14 38 86 34 32 41	7 14 38 90 36 34 43	7 14 38 100 40 36 45	7 14 38 106 42 38 47
98 7 8 0	98 7 8 0	98 7 8 0	98 7 8 0	98 7 8 0

mm 40 R
mm 40 sts

mm 40 R
border

cm sleeve
length



Neckband

103	100
158	259
162	3
64	16
98	3
7	98
9	6
0	8
38	38
25	25
3	3
3	42
42	47
97	97
3	3
0	0

Front band


mm 40 R	100
mm 40 sts	259
3	3
16	16
3	3
3	131
98	131
6	131
8	131
38	131
25	131
3	131
3	131
42	131
47	131
97	97
3	3
0	0

mm 40 R

mm 40 sts

cm neck
opening

cm total
length



BX↔
BX←

Coloured trimming:

Following the armhole shaping, use punchcard 46b from row 72–08 with trimming colour red and from row 08–40 with trimming colour blue. On the sleeve, 36 rows before the end, knit only red trimming.

Bands: 2:2 rib.
Front bands: K/K.

Flashing figures:

- 1 Tubular cast on for 2:2 rib.
Front bands: Tubular cast on with all needles.
- 2 Bring all needles into Working Position. Knit the first 2 rows with lock front and back CX. Then set lock for pattern.
- 3 Cast off all remaining stitches.
- 4 Collar: a few rows contrast yarn, release.

Note: Front bands:

the message "+ 1" means: work a buttonhole here over 6 needles.

To make up:

Block and press parts. Join shoulder seams. Measure neck opening and knit neckband. Sew neckband to outside of neck opening, st by st, backstitching through the open loops and unravelling contrast yarn. Fold in half to inside and catch down. Measure along front edges and knit two front bands, one of which with buttonholes. Sew front bands in position. Set in sleeves. Join side and sleeve seams.

Front part

92	98	110	122	134	146	158	164
60	60	60	60	60	60	60	60
155	155	155	155	155	155	155	155
86	88	94	100	104	110	114	120
66	68	72	76	80	84	88	92
66	68	72	76	80	84	88	92
195	195	195	195	195	195	195	195
7	7	7	7	7	7	7	7
11	11	11	11	11	11	11	11
38	38	38	38	38	38	38	38
86	88	94	100	104	110	114	120
66	68	72	76	80	84	88	92
17	18	20	22	24	26	28	30
38	40	43	46	49	52	55	58
228	228	228	228	228	228	228	228
6	6	6	6	6	6	6	6
191	191	191	191	191	191	191	191
149	150	152	155	157	158	160	163
43	46	50	53	56	60	63	66
67	67	67	67	67	67	67	67
191	191	191	191	191	191	191	191
134	134	135	135	135	137	137	137
40	43	47	50	53	57	60	63
0	0	0	0	0	0	0	0

Back

92	98	110	122	134	146	158	164
60	60	60	60	60	60	60	60
155	155	155	155	155	155	155	155
86	88	94	100	104	110	114	120
66	68	72	76	80	84	88	92
66	68	72	76	80	84	88	92
195	195	195	195	195	195	195	195
7	7	7	7	7	7	7	7
11	11	11	11	11	11	11	11
38	38	38	38	38	38	38	38
86	88	94	100	104	110	114	120
66	68	72	76	80	84	88	92
17	18	20	22	24	26	28	30
38	40	43	46	49	52	55	58
228	228	228	228	228	228	228	228
6	6	6	6	6	6	6	6
191	191	191	191	191	191	191	191
149	150	152	155	157	158	160	163
43	46	50	53	56	60	63	66
67	67	67	67	67	67	67	67
191	191	191	191	191	191	191	191
134	134	135	135	135	137	137	137
40	43	47	50	53	57	60	63
0	0	0	0	0	0	0	0

Neckband

103
158

mm 40 R
mm 40 sts

162
64


cm neck opening

97
6
0

mm 40 R
mm 40 sts

cm chest

cm total length



Sleeve

92	98	110	122	134	146	158	164
60	60	60	60	60	60	60	60
155	155	155	155	155	155	155	155
46	50	52	54	58	60	62	64
18	19	20	21	22	23	24	25
18	19	20	21	22	23	24	25
195	195	195	195	195	195	195	195
7	7	7	7	7	7	7	7
11	11	11	11	11	11	11	11
38	38	38	38	38	38	38	38
64	68	72	78	84	88	94	100
25	26	28	30	32	34	36	38
18	19	21	23	25	27	31	35
32	34	37	40	43	46	51	56
68	68	68	68	68	68	68	68
6	6	6	6	6	6	6	6
191	191	191	191	191	191	191	191
147	149	149	152	155	156	159	162
46	50	53	56	60	63	66	70
70	70	70	70	70	70	70	70
6	6	6	6	6	6	6	6
191	191	191	191	191	191	191	191
147	149	149	152	155	156	159	162
43	46	50	53	56	60	63	66
187	188	187	187	188	187	187	188
133	133	135	135	135	137	137	137
0	0	0	0	0	0	0	0



Back

92	98	110	122	134	146	158	164
60	60	60	60	60	60	60	60
155	155	155	155	155	155	155	155
86	88	94	100	104	110	114	120
66	68	72	76	80	84	88	92
66	68	72	76	80	84	88	92
195	195	195	195	195	195	195	195
7	7	7	7	7	7	7	7
11	11	11	11	11	11	11	11
38	38	38	38	38	38	38	38
86	88	94	100	104	110	114	120
66	68	72	76	80	84	88	92
17	18	20	22	24	26	28	30
38	40	43	46	49	52	55	58
228	228	228	228	228	228	228	228
6	6	6	6	6	6	6	6
191	191	191	191	191	191	191	191
149	150	152	155	157	158	160	163
43	46	50	53	56	60	63	66
67	67	67	67	67	67	67	67
191	191	191	191	191	191	191	191
134	134	135	135	135	137	137	137
40	43	47	50	53	57	60	63
0	0	0	0	0	0	0	0

mm 40 R
mm 40 sts

mm 40 R
border

cm sleeve
width

cm sleeve
length

1 R BX←
AX
6 R BX
AX
1 R BX
N

1 R BX←
AX
6 R BX
AX
1 R BX
N

4

To make up:

Pin parts out to size and leave to dry under a damp cloth. Sew sleeves between front and back parts, with shorter part to the front. Measure neck opening and knit neckband. Sew neckband to outside of neck opening, st by st, back-stitching through the open loops and unravelling contrast yarn. Mitre point. Join sleeve and side seams.

Front part

110	122	134	146	158
108 416	108 416	108 416	108 416	108 416
40 68 68 195	42 72 72 195	46 76 76 195	48 80 80 195	50 84 84 195
7 6 38 40 62	7 6 38 42 66	7 6 38 46 70	7 6 38 48 74	7 6 38 50 80
16 40	18 42	20 46	21 50	22 52
233 7 2 178 145 146 7 12 187 133 67 191 138 23 0	233 7 2 178 145 155 7 12 187 135 67 191 139 24 0	233 7 2 178 145 155 7 14 189 137 67 191 139 28 0	233 7 2 178 145 146 7 19 189 139 67 191 139 30 0	233 7 2 178 145 146 7 19 189 139 67 191 139 30 0

Back

110	122	134	146	158
108 160	108 160	108 160	108 160	108 160
84 68 68 195	92 72 72 195	96 76 76 195	100 80 80 195	108 84 84 195
7 6 38 40 62	7 6 38 42 66	7 6 38 46 70	7 6 38 50 74	7 6 38 50 80
16 40	18 42	20 46	21 50	22 52
105 7 2 153 164 146 7 10 187 133 0	105 7 2 178 145 146 7 13 187 135 0	105 7 2 178 153 164 7 15 189 137 0	105 7 2 153 164 146 7 17 189 139 0	106 7 2 161 153 145 7 14 146 141 0

Sleeve

110	122	134	146	158
108 160	108 160	108 160	108 160	108 160
48 19 19 195	52 20 20 195	54 21 21 195	56 22 22 195	58 23 23 195
7 1 38 66	7 1 38 28	7 1 38 29	7 1 38 30	7 1 38 31
24 35	26 38	28 41	30 44	34 49

mm 40 R
mm 40 sts
mm 40 R border
cm sleeve width
cm sleeve length



Front band

100 259				
3 14 3 3 98 5 8 38 23 3 3 30 32				
cm buttonhole				
mm 40 R				
cm total length				

Material:



fairly fine wool (530 m length per 100 g, 166 yds per 1 oz), 210–420 g red, 110–220 g white, 70–140 g blue, 5 buttons.

Stitch size:

Fairisle = 3½, 2:2 rib = 3, K/K = 2¾.

Pattern:

Fairisle with DECO punchcard 31.



BX↔
BX←

Colour sequence:

Begin with 24 rows red in fairisle stitch, then in blue/white with DECO punchcard 31. However, each time a figure on black background appears in the right-hand window of the card reader, set DECO to zero and knit 24 rows red in fairisle stitch.

Welt: 2:2 rib.

Front band: K/K.

Flashing figures:

- 1 Tubular cast on for 2:2 rib.
Front band: tubular cast on with all needles.
- 2 Bring empty needles into Working Position. Knit the first 2 rows with lock front and back CX. Then set lock for pattern.
- 3 Cast off all remaining stitches.
Front band: a few rows contrast yarn, release.

Note: Front band:

the message "+1" means: work a buttonhole here over 6 stitches.

To make up:


Block and press parts. Join shoulder, side and sleeve seams. Measure jacket front edge to where the last buttonhole is required as well as measuring the total length. Insert both measurements and knit front band. Sew front band in position with mattress stitch, unravel contrast yarn and neaten loose stitches. Set in sleeves. Attach buttons.

Trousers (2nd part knitted with reversed shapings)

116	134	146	158
38	38	38	38
154	154	154	154
122	132	140	148
47	51	54	57
47	51	54	57
38	38	38	38
122	132	140	148
3	3	3	3
3	3	3	3
47	54	62	67
69	80	90	97
72	72	73	74
144	144	144	144
175	175	175	175
5	5	5	5
150	150	167	167
191	141	5	5
129	191	142	151
89	129	191	5
3	106	130	191
71	72	110	129
144	144	73	115
183	183	144	73
5	5	183	144
150	167	5	183
142	5	167	5
7	142	5	167
85	7	151	5
99	100	5	151
71	99	7	5
1	71	104	7
13	1	99	115
0	13	71	99
	0	1	71
		13	1
		0	13
			0

mm 40 R
mm 40 sts

cm total length



Material:


270–540 g fairly fine wool
(530 m length per 100 g, 166 yds per 1 oz).

Stitch size:

Pattern = $3\frac{1}{2}$, stocking stitch = $4\frac{1}{2}$.

Pattern:

Pattern:
Single bed tuck stitch pattern.



Waistband: stocking stitch

Flashing figures:


- 1 Tubular cast on for 1:1 rib.
Knit 5 rows then transfer all stitches to front bed for tuck stitch pattern.
 - 5 A few rows contrast yarn, release.
 - 7 Continue to knit stocking stitch.

To make up:

Block and press parts. Join leg and seat seams. Fold waistband in half to inside and sew in position, unravel contrast yarn. Insert waist elastic. Adjust legs to required length.


Front part

3	6	9	12	months
70 140	70 140	70 140	70 140	
				mm 40 R
				mm 40 sts
58	68	72	78	
20	24	25	27	
20	24	25	27	
194	194	194	194	
70	70	70	70	
5	5	5	5	
226	226	226	226	
7	7	7	7	
60	62	66	69	
68	68	68	68	
184	184	184	184	
140	142	143	144	
7	7	7	7	
3	3	6	6	
0	0	0	0	




Back (2nd part knitted with reversed shapings)

3	6	9	12	months
70 396	70 396	70 396	70 396	
				mm 40 R
				mm 40 sts
42	54	56	62	
15	19	20	22	
15	19	20	22	
194	194	194	194	
70	70	70	70	
5	5	5	5	
226	226	226	226	
7	7	7	7	
60	62	66	69	
68	68	68	68	
184	184	184	184	
152	162	163	167	
7	7	7	7	
3	3	6	6	
0	0	0	0	



Sleeve

3	6	9	12	months
70 140	70 140	70 140	70 140	
				mm 40 R
				mm 40 sts
54	56	59	62	
19	20	21	22	
19	20	21	22	
194	194	194	194	
70	70	70	70	
5	5	5	5	
98	98	98	98	
7	7	7	7	
23	26	29	32	
0	0	0	0	



Neckband

103		
158		
	mm 40 R	
	mm 40 sts	
162		
64		
	cm neck opening	
97		
4		
0		

Material:


Baby wool
(405 m length per 100 g, 127 yds per 1 oz)
40–60 g green, 30–50 g pale green.

Stitch size:

Tuck stitch = 5, 1:1 rib = 2^{3/4}.

Pattern:

2-coloured tuck stitch pattern with
DECO punchcard 39.



GX
AX←
2 R
pale green
2 R
green

All bands: 1:1 rib.

Flashing figures:

- 1 Tubular cast on for 1:1 rib.
- 2 Transfer all stitches to front bed for pattern.
- 3 Divide work, continue to knit at right.
- 4 End of first shoulder, a few rows with contrast yarn, release. To knit second shoulder, press key GO.
- 5 A few rows contrast yarn, release.

To make up:

Block and press parts. Join shoulder seams with graft stitch. Sew sleeves in position, st by st, backstitching through the open loops and unravelling contrast yarn. Measure neck opening and knit neckband. St by st, backstitching through the open loops and unravelling contrast yarn, sew neckband in position. Join side and sleeve seams. Attach hook and button.


Baby's pants

3	6	9	12
70	70	70	70
140	140	140	140
72	75	78	83
25	26	27	29
25	26	27	29
195	195	195	195
70	70	70	70
7	7	7	7
4	4	4	4
104	104	104	104
7	7	7	7
32	35	38	41
168	168	168	168
7	7	7	7
128	128	128	128
64	64	64	64
1	1	1	1
4	4	4	4
0	0	0	0

months

mm 40 R

mm 40 sts

**Material:**

Baby wool
(405 m length per 100 g, 127 yds per 1 oz)
35–65 g green, 25–45 g pale green.

Stitch size:

Stocking stitch = 5, 1:1 rib = 2 $\frac{3}{4}$.

Pattern:

Stocking stitch with stripes:
2 R green, 2 R pale green.
Bands: 1:1 rib.

Flashing figures:

- 1 Tubular cast on for 1:1 rib.
- 2 Transfer all stitches to front bed for stocking stitch.
- 5 Loosely cast off all stitches.
- 7 Transfer stitches for 1:1 rib, put empty needles out of Working Position.

To make up:

Block and press parts. Join the two halves with mattress stitch. Join seat seam. Fold waistband in half to inside and sew in position. Insert waist elastic.

Front / Back

3	6	9	12
97	97	97	97
125	125	125	125
75	80	82	86
24	25	26	28
24	25	26	28
195	195	195	195
97	97	97	97
7	7	7	7
3	3	3	3
101	101	101	101
7	7	7	7
32	36	39	41
64	64	64	64
1	1	1	1
5	5	5	5
0	0	0	0

Sleeve

months	3	6	9	12
mm 40 R	97	97	97	97
mm 40 sts	125	125	125	125
	40	46	50	53
	13	15	16	17
	13	15	16	17
	195	195	195	195
	97	97	97	97
	7	7	7	7
	3	3	3	3
	100	100	100	100
	63	63	63	63
	128	128	128	128
	144	148	153	157
	4	4	4	4
	0	0	0	0



Material:

Baby wool
(400 m length per 100 g, 125 yds per 1 oz)
70–100 g white, a remainder green.

Stitch size:

Stocking stitch = 5, 1:1 rib = 2 3/4.

Pattern:

Stocking stitch.
All bands: 1:1 rib.

Flashing figures:

- 1 Tubular cast on for 1:1 rib.
- 2 Transfer all stitches to front bed for stocking stitch.
- 5 Front and back part: cast off loosely.
Sleeves: a few rows contrast yarn, release.
- 7 Transfer stitches for 1:1 rib, put empty needles out of Working Position.

To make up:

Block and press parts. Pin 1:1 rib neckbands one on top of the other. Attach sleeves, st by st, backstitching through the open loops and unravelling contrast yarn. Join sleeve and side seams. Attach 2 press studs if required on either side of neck opening to hold bands in position.

Leg


3	6	9	12
97	97	97	97
125	125	125	125
82	86	88	94
26	27	28	30
26	27	28	30
195	195	195	195
97	97	97	97
7	7	7	7
3	3	3	3
101	101	101	101
36	36	36	36
7	7	7	7
24	29	32	37
190	190	190	190
130	130	130	130
0	0	0	0

months

mm 40 R
mm 40 sts**Top**

3	6	9	12
97	97	97	97
125	125	125	125
144	152	156	168
47	48	50	54
47	48	50	54
107	107	107	107
7	7	7	7
28	33	36	41
64	64	64	64
1	1	1	1
7	7	7	7
3	3	3	3
184	184	184	184
161	163	164	171
191	191	191	191
129	129	129	129
131	131	131	131
0	0	0	0

months

mm 40 R
mm 40 sts**Material:**


Baby wool
(400 m length per 100 g, 125 yds per 1 oz)
80–110 g green, 60–80 g white.

Stitch size:

Tuck stitch = 4, 1:1 rib = 2 $\frac{3}{4}$.

Pattern:

Double bed tuck stitch pattern.



All bands and straps: 1:1 rib.

Flashing figures:

- 1 Tubular cast on for 1:1 rib.
Note: Cast on at left of centre of bed for second leg.
- 2 Set lock for pattern.
- 3 First leg: a few rows contrast yarn, release.
Second leg: return stitches of first leg to needles of machine adjoining second leg.
Enter programme for top part and continue to knit.
- 4 Top part: cast off loosely.
- 5 Set lock for 1:1 rib.

To make up:

Join leg, seat and back seams. Knit straps to required length in 1:1 rib with 11 stitches at front and 10 stitches at back. Attach to back part. Sew buttons to front part and attach loops to match.

Front part

6	12	18
96	96	96
154	154	154
28	32	34
3	3	3
3	3	3
65	65	65
3	3	3
70	70	70
71	71	71
65	65	65
5	5	5
24	24	24
2	2	2
152	152	152
195	195	195
7	7	7
40	46	50
68	68	68
7	7	7
17	20	22
186	186	186
137	141	143
70	70	70
7	7	7
11	14	16
161	161	161
189	189	189
129	129	129
2	2	2
0	0	0

months

mm 40 R 1:1 rib
mm 40 sts 1:1 rib

mm 40 R stitch pattern



Neckband Sleeve band

103	
158	
	mm 40 R
	mm 40 sts
162	
64	
	cm neck armhole
96	
3	
0	

Material:

Baby wool
(400 m length per 100 g, 125 yds per 1 oz)
120–150 g green, 10–20 g white, 10–20 g pink.

Stitch size:

1:1 rib = 3½, garter stitch = 6.

Pattern:

Yoke, legs and all bands: 1:1 rib.
Trouser part: garter stitch with U80,
changing colour every alternate row.

Back

6	12	18
96	96	96
154	154	154

months

mm 40 R 1:1 rib
mm 40 sts 1:1 rib

mm 40 R stitch pattern



Front band

90
259

mm 40 R

3

4

3

3

99

7

1

8

38

26

3

3

27

30

97

2

0

cm length
band

Flashing figures:

- 1 Tubular cast on for 1:1 rib.
- 2 Transfer from garter stitch to 1:1 rib.
Put empty needles out of Working Position.
- 3 Divide work, continue to knit at right.
- 4 End of first shoulder, to knit second shoulder press key GO.
- 5 A few rows with contrast yarn, release.
- 6 Place stitches of first leg on to deckercomb.
Cast on for second leg on left side of bed.
- 7 Transfer all stitches for garter stitch.
- 8 Return stitches of first leg to needles of machine adjoining second leg and continue to knit with all needles.

Note:

When knitting the front band, the message "+ 1" means: transfer centre stitch to adjoining needle to make buttonhole.

To make up:

Block and press parts very lightly. Graft together shoulders, unravel contrast yarn. Join side seam as far as yoke. Measure neck and armhole openings and knit bands accordingly. Sew bands in position on the outside, st by st, back-stitching through the open loops and unravelling contrast yarn. Measure front edge for front bands, knit one with and one without buttonholes. Sew front bands in position with mattress stitch. Join seat seam. Attach buttons.

Front part

1	3	6	9	12	16
100	100	100	100	100	100
132	132	132	132	132	132
104	108	116	120	128	132
34	36	38	40	42	43
34	36	38	40	42	43
101	101	101	101	101	101
7	7	7	7	7	7
29	33	41	47	53	59
248	248	248	248	248	248
128	128	128	128	128	128
173	175	179	181	185	187
228	228	228	228	228	228
7	7	7	7	7	7
11	13	13	15	15	17
188	188	188	188	188	188
135	136	136	137	139	139
67	67	67	67	67	67
184	184	184	184	184	184
133	133	135	135	135	136
5	5	5	5	5	5
0	0	0	0	0	0

Back



months	1	3	6	9	12	16
mm 40 R	100	100	100	100	100	100
mm 40 sts	388	388	388	388	388	388
52	54	58	60	64	66	
17	18	19	20	21	22	
17	18	19	20	21	22	
101	101	101	101	101	101	
7	7	7	7	7	7	
29	33	41	47	53	59	
248	248	248	248	248	248	
128	128	128	128	128	128	
147	148	150	151	153	154	
228	228	228	228	228	228	
7	7	7	7	7	7	
11	13	13	15	15	17	
188	188	188	188	188	188	
135	136	136	137	139	139	
67	67	67	67	67	67	
184	184	184	184	184	184	
133	133	135	135	135	136	
2	2	2	2	2	2	
0	0	0	0	0	0	

Sleeve

months	1	3	6	9	12	16
mm 40 R	100	100	100	100	100	100
mm 40 sts	132	132	132	132	132	132
54	58	60	64	68	72	
18	20	20	22	22	24	
18	20	20	22	22	24	
194	194	194	194	194	194	
100	100	100	100	100	100	
5	5	5	5	5	5	
98	98	98	98	98	98	
7	7	7	7	7	7	
22	25	29	33	35	37	
0	0	0	0	0	0	

mm 40 R

mm 40 sts

**Material:**


Baby wool
(400 m length per 100 g, 125 yds per 1 oz)
60–80 g pink, 30–40 g dark pink,
30–40 g white.

Stitch size:

5

Pattern:

2-coloured tuck stitch pattern with
DECO punchcard 30.



GX
AX←

Flashing figures:

- Front and back part: tubular cast on for 1:1 rib, then transfer all stitches to front bed for pattern.
Sleeves: closed cast on for tubular.
- Transfer all stitches to front bed for pattern.
- Divide work, continue to knit at right.
- End of first shoulder, to knit second shoulder press key GO.
- Front part and back: cast off all remaining stitches.
Sleeves: a few rows contrast yarn, release.
- Press key STOP, then knit a few rows with contrast yarn, release.
Return stitches of skirt to needles of machine and decrease indicated number of stitches by placing 2 stitches on to each needle.
To continue knitting, press key GO.

To make up:

Block and press parts. Graft together shoulders, unravel contrast yarn. Attach sleeves, st by st, backstitching through the open loops and unravelling contrast yarn. Join sleeve and side seams. Join part of back seam or leave completely open as desired. Attach hooks and buttons.

Colour sequence:

Skirt: 2 R pink
2 R dark pink
Bodice: 2 R white
2 R pink

Cuffs: stocking stitch, tubular

Skirt

92	104	116
92	92	92
151	151	151
160	172	174
42	45	46
42	45	46
38	38	38
160	172	174
42	45	46
42	45	46
25	31	38
39	47	54
0	0	0



mm 40 R
mm 40 sts

cm total length dress

Yoke front

92	104	116
98	98	98
118	118	118
76	84	90
22	25	26
22	25	26
228	228	229
7	7	7
18	20	20
188	189	191
145	146	149
68	69	128
161	161	70
179	178	169
164	145	153
4	173	188
0	5	129
0	137	6
		0

mm 40 R
mm 40 sts



Yoke back

92	104	116
98	98	98
374	374	374
38	42	45
11	12	13
11	12	13
100	100	101
7	7	7
18	20	20
188	189	191
145	146	149
0	0	128
		0

mm 40 R
mm 40 sts



Sleeve

92	104	116
92	92	92
151	151	151
74	76	80
28	29	30
28	29	30
98	98	98
7	7	7
34	45	52
0	0	0

mm 40 R
mm 40 sts



Material:

280 g medium Mohair/Acrylic
(350 m length per 100 g, 110 yds per 1 oz).

Stitch size:

Guipure pattern = 5¾, stocking stitch = 6¼.

Pattern:

Guipure pattern.



Yoke: stocking stitch.

Trimming:




6 R $\frac{N}{AX}$
6 R $\frac{AX}{N}$

2 R $\frac{GX}{N}$
4 R $\frac{GX}{AX}$

Flashing figures:

- 1 Skirt and sleeves: Arrange needles acc. to diagram, make tubular cast on, then place the stitches marked with and O on to the needles marked with an X.



Yoke: cast on for stocking stitch with contrast yarn.

- 3 Divide work, continue to knit at right.
- 4 End of first shoulder, to knit second shoulder press key GO.
- 5 Skirt and sleeves: place all stitches on a length of contrast yarn.
Yoke: cast off all remaining stitches.

To make up:


Block and press parts. Join shoulder seams. Gather top of sleeves and attach to yoke side edges. Join sleeves, leaving an opening of about 8 cm at the top. Crochet round neck opening and back slit, at the same time working loops to match the buttons. Measure round yoke edge and knit trimming to required length. Sew trimming in position.

Front part

months	months	6	9	86	92	104
96	96	96	96	96	96	96
130	130	130	130	130	130	140
144	156	168	178	176		
44	48	52	56	58		
44	48	52	56	58		
38	38	38	38	38		
144	156	168	178	176		
44	48	52	56	58		
44	48	52	56	58		
19	22	25	27	29		
30	35	39	43	47		
231	233	233	233	233		
248	248	248	248	248		
128	128	128	128	128		
193	199	205	210	209		
6	7	7	7	7		
48	1	3	6	7		
7	56	56	56	56		
10	129	131	133	134		
68	7	7	7	7		
184	12	12	14	16		
136	68	68	68	68		
7	184	184	184	184		
1	136	136	138	138		
0	7	7	7	7		
1	3	3	3	4		
0	0	0	0	0		

mm 40 R
mm 40 sts

cm total length




Back

months	months	6	9	86	92	104
96	96	96	96	96	96	96
130	130	130	130	130	130	140
144	156	168	178	176		
44	48	52	56	58		
44	48	52	56	58		
38	38	38	38	38		
144	156	168	178	176		
44	48	52	56	58		
44	48	52	56	58		
19	22	25	27	29		
30	35	39	43	47		
231	233	233	233	233		
248	248	248	248	248		
128	128	128	128	128		
193	199	205	210	209		
6	7	7	7	7		
48	1	3	6	7		
7	56	56	56	56		
10	129	131	133	134		
68	7	7	7	7		
184	12	12	14	16		
136	68	68	68	68		
7	184	184	184	184		
1	136	136	138	138		
0	7	7	7	7		
1	3	3	3	4		
0	0	0	0	0		

mm 40 R
mm 40 sts

cm total length

**Material:**

200–300 g medium cotton yarn
(420 m length per 100 g, 132 yds per 1 oz).


Stitch size:

Lace pattern = 4 1/4, stocking stitch = 5 1/2.

Pattern:

Skirt: lace pattern with U70 or U80 and DECO punchcard 70.

Bodice: stocking stitch.



2 R N
BX
—↑ —↓

Note:

for size 104 the test square for 40 sts must equal at least 140 mm.

Flashing figures:

- 1 Tubular cast on for 1:1 rib, then transfer all stitches to back bed for pattern.
- 3 Divide work, continue to knit at right.
- 4 End of first shoulder, knit a few rows with contrast yarn, release. To knit second shoulder, press key GO.
- 5 A few rows contrast yarn, release.
- 6 Press key STOP, knit a few rows with contrast yarn, release.
Return stitches of skirt to needles of machine and decrease stitches as indicated by placing 2 stitches on to each needle. To continue knitting, press key GO.

Should the measurement of the test square for the bodice be very different, press key E to recall the programme once more. Now replace the third and fourth figure with the figures of the measurements of the new test square.

To make up:

Block and press parts. Graft together shoulder seam, unravel contrast yarn. Join side seams. Crochet round neck and armhole openings.

MADAG Maschinen- und Apparatebau Dietikon AG
CH-8953 DIETIKON/Schweiz-Suisse-Suiza-Switzerland

33.205.73/6 englisch