


We make Superior LATCH NEEDLES for
ALL KINDS of Knitting Machines.

~~PRICE~~ LIST OF PARTS



Acme Automatic Knitter



❧ ACME ❧

Knitting Machine and Needle Co.

Office and Factories;
FRANKLIN, New Hampshire.

*The price list in this
catalogue is obsolete*



~~A 50 per cent advance on all list prices in this Catalogue prevails until notice to the contrary.~~

~~All list prices are subject to change without notice.~~
November 15, 1919.

Plate No. 1.

FRAME, MAIN SHAFT and DRIVING PARTS.

470 Transfer Cup Holder Shaft Bracket .25	495 Tight Pulley Pinion .200
471 Transfer Cup Holder Shaft Bracket Screw .05	496 Loose Pulley .50
472 Transfer Cup Holder Shaft Complete .75	497 Clutch, "Two Pin" .200
473 Transfer Cup Holder .50	497A Complete .2.75
474 Transfer Cup Holder Set Screw .03	497A Three Pin Clutch .200
475 Crank .40	497 Complete .2.50
475 Complete .75	498 Clutch Pin Taper .30
477 Crank Handle .05	499 Clutch Pin Straight .30
39 Set Screw .03	500 Spring .05
478 Crank Handle .05	501 Clutch Screw .02
479 Crank Handle Pin .10	502 Segment Gear .1.75
480 Crank Handle Pin .10	17 Screw .03
481 Bevel Gear 3 3-4 inch .2.50	503 Segment Gear Link .80
17 Bevel Gear Set Screw .03	504 Segment Gear Cover .75
482 Bevel Gear Shaft Box .60	42 Cover Screw .02
272 Screw .05	505 Segment Pinion .2.00
483 Bevel Gear Shaft .80	506 Segment Pinion Collet .75
484 Bevel Gear Cover .30	507 Segment Pinion Collar .25
42 Bevel Gear Cover Screw .02	30 Set Screw .03
485 Main Shaft Box Fork Bracket .1.50	508 Segment Gear Shaft .2.75
16 Fork Bracket Cap Screw .03	509 Segment Gear Shaft Crank .25
486 Main Shaft Box Fork .50	510 Segment Gear Shaft Crank Link .25
486 Complete .80	511 Pattern Wheel Feed Adj. Collar .25
17 Fork Bracket Set Screw .03	511S Screw .03
487 Shaft Box Left .40	79 Nut .05
13 Screw .10	30 Screw .03
14 Nut .05	512 Pattern Wheel Feed Lever .50
488 Main Shaft Gear .2.25	513 Pattern Wheel Feed Lever Link .25
17 Main Shaft Gear Set Screw .03	514 Pattern Wheel Feed Spring .05
489 Bevel Gear Ring 4 inch .1.25	515 Transfer Cup Holder .15
490 Shaft Box, Right .40	515S Transfer Cup Holder Spring .03
491 Main Shaft .2.75	516 Large Gear Cam Right .20
492 Spline .10	3 Cam Screw .03
493 Screw .03	517 Large Gear Cam Left .20
494 Tight Pulley .50	4 Cam Screw Washer .01
	518 Large Gear Stud .80

When ordering parts, please give the machine number, diameter of Needle Cylinder, and Number of Needles for which they are required. When ordering Sinkers, Points and Needles, please be particular to specify Style and Gauge, or else send samples. All Diameters are taken between the backs of opposite needles.

Plate No. 2.

PATTERN MECHANISM and WHITE CUFF STOP MOTION.

White Cuff Stop Motion.

X1 Link .15	544X Spring .05
X2 Trip Cam .10	545 Cam Roll .05
X3 Trip Rod .10	546 Screw .10
X4 Shaft Box .10	547 Plate .50
XX Screw .03	548 Hand Lever for Heel and Toe Ratchet .25
X5 Crank .15	549 Pawl .20
X6 Trip on Pattern Gear .15	549X Spring .05
X7 Link .10	550 Ratchet 1.00
X8 Shaft .10	42 Screw .02
	551 Lever .50
	551X Spring .05
	552 Pawl .20
	552X Spring .05
	553 Cam Roll .02
	554 Retain Pawl .25
	555 Adj. Screw .10
	79 Nut .05
	556 Heel and Toe Trip .75
	557 Friction .05
	558 Screw .03
	559 Stop Latch .50
	559X Spring .05
	560 Screw .10
	561 Trip Collar .10
	561X Spring .05
	150 Screw .03
	562 Shaft .05
	563 Retain Lever .10
	150 Screw .03
	564 Feed Cam Stud .10
	565 Feed Cam .40
	566 Adj. Arm .15
	566S Cap Screw .03
	4 Washer .01
	Parts for Loose Pattern Gear.
	567.8 Feed Stop Lever .25
	569 Link .15
	570 Indicator .15
	571 Indicator Pin .05
	572 Dial .75
	48 Screw .02
	573 Cap .50
	574 Arm .50
	575 Thumb Nut .10
	576 Spring .05

When ordering parts, please give the machine number, diameter of Needle Cylinder, and Number of Needles for which they are required. When ordering Sinkers, Points and Needles, please be particular to specify Style and Gauge, or else send samples. All Diameters are taken between the backs of opposite needles.

Plate No. 3.

SHIPPER MECHANISM and LOOPER LOOSE
COURSE DEVICE.

577 Clutch Shifter	2.25		
577 Complete	4.60		
72 Set Screw03		
578 Stud40		
579 Plunger Spring10		
129 Set Screw03		
580 Slide Link20		
581 Feed Stop Connect Link20		
582 Plunger Slide Connect Link15		
583 Plunger Slide60		
584 Screw02		
585 Right Plunger35		
586 Left Plunger35		
587 Right Plunger Screw10		
588 Left Plunger Screw10		
589 Right and Left Plunger Roll10		
590 Rocker Arm Box Stud10		
591 Rocker Arm Stud10		
592 Rocker Arm Box50		
593 Rocker Arm25		
594 Friction Spring05		
595 Washer02		
596 Clutch Fork60		
597 Clutch Fork Stud30		
598 Connect Link10		
599 Fork Pin Block05		
150 Set Screw03		
600 Fork Pin Front10		
601 Clutch Collar10		
602 Clutch Connect Link15		
603 Shifter Lock30		
604 Lock Spring10		
Spring Pulley.			
495A Pulley50		
495B Sleeve75		
495S Pinion	2.00		
495S Complete	4.50		
495D Spline10		
495T Spring75		
		Belt Shifter Parts.	
		605 Guide Pin10
		606 Slide20
		607 Slide Block30
		150 Screw03
		608 Spring10
		608A Cushion Spring10
		609 Stud Nut05
		609S Extension Nut10
		610 Crank15
		611 Crank Link25
		612 Crank Link Trip Slide15
		613 Crank Set Screw03
		614 Nut03
		615 Trip Slide Screw02
		616 Adj. Screw05
		89 Adj. Screw Nut03
		617 Rod10
		618 Handle15
		619 Belt Fingers25
		620 Take-up Shifter60
		621 Stud35
		622 Stop Lever30
		623 Stop Lever Link20
		624 Feed Stop 3 Arm Lever30
		Looper Loose Course.	
		L1 Complete	1.20
		L1 Lever75
		L2 Adj. Arm10
		L3 Adj. Screw for L205
		L4 Nut for L303
		L5 Body Screw for L203
		L6 Latch25
		L7 Catch10
		L8 Screw for L702
		L9 Setting Latch15
		L10 Setting Latch Bracket25
		L11 Screw for L1002
		L12 Spring for L110
		L13 Con. Link for L1 and L915
		L14 Trip Pin for Large Gear03

When ordering parts, please give the machine number, diameter of Needle Cylinder, and Number of Needles for which they are required. When ordering Sinkers, Points and Needles, please be particular to specify Style and Gauge, or else send samples. All Diameters are taken between the backs of opposite needles.

Plate No. 4.

NEEDLE CYLINDER and PARTS.

625 Cam Plate40	670 Switch Shifter Bed50
625 Complete	1.25	670 Complete	1.16
626 Outside Cam50	42 Screw02
627 Inside Cam30	671 Switch Cam Shifter, Upper25
628 Right Adj. Outside Cam25	176 Spring03
629 Left Adj. Outside Cam25	672 Switch Cam Shifter, Lower25
630 Cam Ring	2.00	672C Cap10
630 Complete	3.50	44 Screw03
631 Cap15	673 Trip Post Side25
631A Sinker Gate Cap10	170 Spring05
632 Lug10	674 Pin03
633 Cam Screw02	675 Trip Post Front25
634 Friction Box05	676 Needle Cylinder Band05
634 Complete15	677 Tension Ring50
635 Friction05	678 Tension Lever15
636 Screw02	200 Screw02
637 Adj. Screw03	60 Screw05
638 Adj. Screw Nut02		
639 Blind Set Screw03	Tension Levers and Raising Device.	
640 Inside Sinker Ring, per slot00%	679 Complete45
641 Outside Sinker Ring, per slot01%	679 Heel and Toe Lever40
642 Screw02	680 Latch10
642S Key02	880S Screw02
643 Needle Cylinder, per slot06	681 Connect Plate10
643 Complete per slot15	681S Screw02
644 Skeleton, per bar02%	682 Complete50
645 Screw05	682 Loose Tension Stud20
646 Spring Band Ring60	683 Plate25
185 Screw02	683S Screw02
647 Brass Ring, per slot01	684 Flat Spring05
648 Skeleton Bar02	70 Screw02
		685 Complete20
		685 Box10
		686 Lever Spring05
		686S Screw02
		687 Needle Cylinder Lug10
		687A Needle Cylinder Lug10
		70 Screw02
		688 Spring Stud05
		689 Tension Lever50
		690 Link25
		691 Roll Lever30
		692 Screw05
		589 Roll10
		693 Tension Rod25
		694 Collar15
		704 Screw03
		695 Lever Collar10
		696 Spring10
		697 Thimble05
		698 Raising Device Handle15
		699 Crank15
		700 Plate10
		701 Stud05
		702 Ring75
669P Ring Lever Pin05		
		Shifter Ring and Parts.	
649 Ring	1.00		
649 Complete	2.50		
650 Lug25		
70 Screw02		
651 Spring Stud05		
652 Cam20		
653 Switch Cam Shifter Pin10		
654 Stop10		
655 Trip Post Cam25		
656 Outside Skeleton Base50		
657 Inside Skeleton Base75		
657 Per Bar02%		
44 Cam Screw03		
666 Ring Holder05		
667 Ring Spring10		
668 Ring Link10		
669S Adj. Screw05		
79 Nut05		
669 Ring Lever25		
165 Spring03		
669P Ring Lever Pin05		

When ordering parts, please give the machine number, diameter of Needle Cylinder, and Number of Needles for which they are required. When ordering Sinkers, Points and Needles, please be particular to specify Style and Gauge, or else send samples. All Diameters are taken between the backs of opposite needles.

RE-ENFORCING and TAKE-UP STAND.

766	Shears	.50	796T	Lower Clamp	.05
766	Complete	.62	797T	Clamp Stud	.15
767	Shears Bracket	.35	797T	Washer	.03
767	Complete	1.75	800	Spring	.05
48	Screw	.02	801	Take-up Stand	2.25
768	Shears Screw	.05	801	Complete	15.00
769	Shears Spring	.05	802	Porcelain	.03
192	Screw	.02	803	Porcelain	.02
770	3-Arm Lever	.35	804	Porcelain	.02
770S	Screw	.05	805	Shear Bell Crank Link	.20
771	Screw	.05	805	Complete	.30
772	Thread Hook	.03	806	Slackner Adj. Stud	.05
773	Connect Wire	.25	807	Nut	.03
774	Bell Crank	.10	808	Washer	.02
775	Yarn Separator	.10	809	Spring	.10
776	Take-up Wire	.10	284	Spring	.05
776A		.10	810	Segment Twister Link	.20
776C		.10	811	Shear Link Bracket	.25
777	Take-up Wire Porcelain	.02	811S	Bracket for X18-X17-X16	.25
778	Balance	.05	812	Link Lever	.25
778B		.05	813	Link Bell Crank	.25
779	Hinge	.15	814	Bell Crank Connect	.10
779C		.15	815	Twister Segment	.60
779T		.15	816	Stud	.15
779S	Screw	.03	204	Screw	.03
780	Screw	.03	817	Nut	.03
781	Spring Collar	.05	818	Washer	.02
782	Spring	.10	819	Spring	.03
782	Complete	.21	820	Take-up Shifter Arm	.15
783	Spring Screw	.03	821	Clamp Screw	.03
784	Spring Binder	.03	822	Latch for 823	.05
785	Shifter	.25	823	Slackner Trip	.20
785	Complete	.35	823	Complete	.35
786	Leather	.03	824	Screw for 823	.03
787	Screw	.02	825	Screw for 822	.02
788	Gear Case	.60	826	Spring for 822	.05
788B		.60	827	Stud for 836	.05
788	Complete	3.50	828	Bell Crank for 837	.25
48	Screw	.02	829	Slackner Collar	.05
789	Stud	.15	150	Set Screw	.03
779T	Take-up Wire Hinge	.15	830	Slackner	.15
785S	Spring Shifter	.25	830	Complete	.35
785A	Spring	.10	831	Connect Wire	.10
785C	Stud	.02	832	Body Screw	.03
785B	Connect Wire	.02	833	Porcelain Eye	.02
790	Ratchet	.30	834	Latch	.25
790T	Case Cover	.30	835	Screw	.03
790T	Complete	3.50	836	Latch Bell Crank	.25
48	Screw	.02	836A		.25
791	Twister Brush Tube	.30	837	Collar Bracket	.15
791T	Brush	1.00	838	Nut for 827	.03
792	Binder Screw	.03	X9	Screw	.03
792T	Complete	.25	X10	Latch	.25
792T	Brush Cover	.25	X10	Complete	.50
793	Gear Pawl	.20	X11	Bracket	.10
298	Screw	.02	X12	Spring	.10
794	Brush Cover Screw	.02	X13	Pinion	.25
795	Pawl	.10	X14	Rack	.35
796	Screw	.02	X15	Link for X16	.10
797	Gear	.40	X16	Short Crank	.15
797	Complete	.45	X17	Shaft	.10
798	Pawl Spring	.03	X18	Long Crank	.15
794T	Nut	.03	X19	Rack Connect	.10
795T	Upper Clamp Holder	.25			

When ordering parts, please give the machine number, diameter of Needle Cylinder, and Number of Needles for which they are required.
When ordering Sinkers, Points and Needles, please be particular to specify Style and Gauge, or else send samples.
All Diameters are taken between the backs of opposite needles.

Plate No. 5.

CAM CYLINDER and PARTS.

703	Cylinder Ring	.40	734	Left Tumbler	.40
215	Screw	.02	735	Right Tumbler	.40
704	Switch Bracket	.50	736	Left Stitch Cam	.60
704	Complete	2.90	737	Right Stitch Cam	.60
705	Switch	1.25	738	Filling-in Piece	.20
225	Screw	.05	739	Center Cam	.50
706	Slide	.15	740	Top Cam A	.50
707	Rack	.45	741	Top Cam D	.50
708	Pinion	.30	742	Top Cam B	.40
708S		.10	743	Top Cam C	.40
709	Spring Pin	.10	744	Center Block	.50
709S	Pin	.10	745	Cam Screw	.02
710	Spring	.03	746	Swing Cam	.35
710S	Spring	.03	747	Spring	.03
710X	Lifter Bracket	1.75	748	Elevating Cam	.35
710X	Complete	3.50	749	Stud	.10
711	Left Lifter Latch	.30	750	Spring Washer	.05
712	Right Lifter Latch	.30	751	Latch Ring	1.00
713	Left Lifter Spring	.05	751	Complete with Brackets	4.50
714	Right Lifter Spring	.05	752	Tube	.03
715	Left Lifter	.40	753	Screw	.02
716	Right Lifter	.40	754	Latch Ring Steel Insert	.25
717	Skeleton Ring Holder	.05	754B	Latch Ring Steel Insert	.25
718	Spring	.03	754X	Screw	.02
719	Knob	.05	755	Pin Cap	.15
720	Spring Cam Block Stud	.10	755X	Screw	.02
721	Latch	.20	756	Plug	.05
722	Spring	.03	757	Spring for Plug	.03
723	Cam Cylinder	5.00	758	Latch Ring Pin	.05
723	Complete	30.00	759	Left Latch Spring	.05
724	Top Cam E	.40	760	Right Latch Spring	.05
725	Top Cam F	.40	761	Right Dropper Latch	.30
726	Top Cam G	.40	762	Left Dropper Latch	.30
727	Filling Cam A	.50	763	Right Dropper	.40
728	Filling Cam B	.50	764	Left Dropper	.40
729	Filling Cam C	.50	60	Screw	.05
730	Left End Cam	.50	765	Dropper Bracket	1.75
731	Right End Cam	.50	765	Complete	3.50
732	Left Tumbler Spring	.05	218	Screw	.02
733	Right Tumbler Spring	.05			

When ordering parts, please give the machine number, diameter of Needle Cylinder, and Number of Needles for which they are required.
When ordering Sinkers, Points and Needles, please be particular to specify Style and Gauge, or else send samples.
All Diameters are taken between the backs of opposite needles.

Plate No. 7.

DOUBLE SOLE ATTACHMENT.

839	Double Sole Latch Ring....	1.50	861	Trip for 85710
839	Complete	3.50	44	Screw03
839A	1.50	862	Screw for 85505
840	Spring05	863	Screw for 87905
841	Depresser Holder15	864	R. Swing Post Cam.....	.15
841S	Screw02	70	Screw02
21S	Screw02	865	Right Post50
842	Depresser05	865	Complete	1.00
843	Rock Shaft Box25	42	Screw02
843S	Rock Shaft Box50	866	Eccentric Pin25
843S	Complete	1.88	181	Screw03
181	Screw03	84	Washer02
89	Nut03	867	Swing Post20
844	Rock Shaft45	868	Swing Stud15
844S	Rock Shaft45	869	Washer03
845	Shaft Cam80	870	Nut03
846	Slide40	871	Spring10
847	Carrier Hinge35	298	Screw02
848	Carrier25	872	Cop Spindle Guide Arm...	.30
848A25	873	Cop Spindle25
849	Screw03	171	Screw02
850	Hinge Pin02	874	Guide Arm Spring03
851	Slide Screw05	875	Box50
852	L. Swing Post Lever25	875	Complete	1.25
852S	Screw05	215	Screw02
853	Spring05	876	Left Post50
854	Center Screw for 85205	876	Complete	1.25
855	Link for 85220	42	Screw02
856	Lock50	877	Cam50
857	Cam Trip25	878	Screw05
858	Latch20	879	L. Swing Post15
859	Screw for 85805	879	Complete	1.25
860	Trip for 85625	880	Cam Spring05
44	Screw03	70	Screw05

When ordering parts, please give the machine number, diameter of Needle Cylinder, and Number of Needles for which they are required.
When ordering Sinkers, Points and Needles, please be particular to specify Style and Gauge, or else send samples.
All Diameters are taken between the backs of opposite needles.

Plate No. 8.

LACE FRONT ATTACHMENT.

881	Case	2.50	912	Complete	3.50
882	Case Cover	1.00	218	Screw02
44	Screw03	913	Tuck Switch Cam	1.00
883	Screw for 88105	914	Main Switch Cam	1.25
884	Ratchet Stud40	225	Screw05
885	Ratchet Lever Bushing.....	.15	915	Switch Pinion30
886	Ratchet Lever50	916	Pin for 923 and 92402
887	Screw for 90310	917	Friction02
888	Slide Equalizer30	918	Friction Spring03
888X	Spring05	919	Segment50
889	Ratchet Stop Lever30	920	Segment50
890	Tuck Stop Lever30	921	Segment Stud05
891	Bottom Slide40	922	Brass Ring Holder15
892	Top Slide40	48	Screw02
893	Lever Cam Roll10	923	Top Cam40
894	Cam Roll Screw05	924	Top Cam40
895	Nut for 894 and 88705	925	Crank Cam Guard25
896	Slide Lever50	926	Crank Cam50
181	Screw03	39	Screw03
897	Slide Adj. Lever20	927	Crank Cam Handle (wood)05
898	Tuck Adj. Lever20	928	Bracket for 92920
899	Retaining Pawl20	70	Screw02
900	Top Push Pawl20	929	Trip Lever for Old P. W.30
900S	Spring05	930	Spring03
901	Bottom Push Pawl20	931	Screw03
902	Ratchet	1.50	932	Latch for 92925
903	Bell Crank for 906 and 90840	933	Screw for 93203
904	Link for 88920	934	Pattern Wheel Cam80
904S	Old Style P. W. Screw05	935	Adj. Cam80
905	Bracket for 904 Old Style P. W.25	936	Trip Cover50
906	Tuck Stop Link15	936	Complete	1.64
906S	Screw05	937	Trip Lever for New P. W.50
79	Nut05	938	Spring03
907	Link to Clutch15	939	Trip Cam20
908	Link for 90525	940	Spring for 93903
909	Link for 93725	941	Latch for 93735
910	Spring05	942	Spring03
911	Pattern Wheel Shaft.....	.50	943	Stud for 93205
912	Switch Bracket75	944	Tucking Screw for 90203

When ordering parts, please give the machine number, diameter of Needle Cylinder, and Number of Needles for which they are required.
When ordering Sinkers, Points and Needles, please be particular to specify Style and Gauge, or else send samples.
All Diameters are taken between the backs of opposite needles.

Plate No. 9.

YARN CHANGING, TIPPING and PLATING
ATTACHMENT.

945 Latch Ring	2.00	993 Take-up Lever	.20
945 Complete	15.00	994 Screw for 993	.03
946 Latch Ring Post	.50	995 Connecting Wire	.10
946 Complete	.90	996 Spring for 993	.03
947 Y. C. Throat Plate	.75	997 Porcelain for 993	.02
948 Plater Throat Plate	.75	998 Clamp Bracket	.50
949 Guard	.05	999 Porcelain for 998	.02
950 Guard Screw	.03	01 Clamp	.10
951 Screw for 947	.03	02 Yoke for 01	.10
952 Left Guide Slide	.25	03 Body Screw for 01	.02
953 Yarn Tube for 954	.20	04 Nut for 03	.02
954 Left Yarn Guide	.75	05 Clamp Adj. Screw	.03
954 Complete	1.80	06 Spring for 05	.02
955 Slide Link	.20	07 Nut for 05	.02
955 Screw for 955	.05	08 Bracket (Loose Course)	.15
956 Post Screw	.02	09 Loose Course Lever	.10
958 Tube Binder Screw	.02	10 Screw for 09	.03
959 Presser Foot	.50	011 Link for 09	.15
959 Complete	.93	012 Adj. Lever	.25
960 Yarn Holder Spring	.02	013 Adj. Screw	.02
961 Screw for 959	.25	014 Screw for 012	.05
962 Right Guide Slide	.25	015 Screw for 011	.03
963 Closer Slide	.30	016 Tension Collar for 09	.10
964 Spring	.05	017 Con. from 022 to 028	.30
965 Cap	.15	018 Con. from 020 to 023	.10
966 Yarn Tube for 967	.20	019 Con. from 028 to 040	.15
967 Right Yarn Guide	.65	020 Change Lever	.35
968 Plaiter Yarn Guide	.75	021 Screw for 020	.10
969 Main Tube for 968	.20	022 Con. Lever	.25
970 Plaiting Yarn Tube	.20	023 Broken Point Lever	.20
971 Washer for 946	.03	024 Tipper Lever	.10
972 Nut for 946	.03	025 Cam for 024	.03
973 Plaiting Post Guide	.25	026 Screw for 025	.03
973S Porcelain for 973	.03	027 Trip Cam Lever	.50
974 Yarn Changer Post Guide	.15	027S Trip Cam	.15
975 Latch Ring Spring	.05	028 Bell Crank for 017	.25
976 Tipper Latch Ring	2.00	029 Screw for 028	.02
976 Complete	10.00	030 Con. Lever for 027	.25
978 Tipper Latch Ring Spring	.05	031 Adj. Screw for 030	.03
979 Tipper Throat Plate	.75	032 Adj. Collar	.15
980 Screw for 974	.03	033 Set Screw for 030	.03
981 Latch Ring Pin	.02	034 Trip Lever for 020	.20
982 Left Yarn Guide	.75	035 Con. Link from 036 to 034	.15
983 Right Yarn Guide	.65	036 Bracket Slide Lever	.15
983 Complete	1.80	037 Link for 036 to 040	.15
984 Left Closer Slide	.30	037S Screw for 037	.03
985 Right Closer Slide	.30	038 Spring for 036	.10
986 Side Take-up Rod	.50	039 Front Bracket	.75
972 Nut for 986	.03	1039 Complete	2.75
987 Bobbin Spindle	.35	040 Slide-Bell Crank	.25
988 Lock Collar	.15	041 Screw for 040	.03
989 Spring	.03	042 Bell Crank for Toe Courses	.50
990 Collar for Spring	.15	043 Shaft for 042	.03
991 Collar for 996	.10	044 Bracket Slide	.45
992 Bracket Collar	.25	1044 Complete	1.00

When ordering parts, please give the machine number, diameter of Needle Cylinder, and Number of Needles for which they are required. When ordering Sinkers, Points and Needles, please be particular to specify Style and Gauge, or else send samples. All Diameters are taken between the backs of opposite needles.

045 Slide Cam	.50	085 Bevel Gear Bracket New Style	.50
X2 Screw for 045	.02	086 Stud for 087	.10
046 Spring for 044	.05	087 Bevel and Spur Pinion	1.25
047 Pinion Shaft Bracket	.25	088 Bevel Pinion	1.00
048 Shaft	.40	089 Spur Gear for Main Shaft	1.50
049 Intermediate Pinion	1.00	090 Stand New Style	1.50
050 Bevel Pinion	1.00	091 Rack Lever	.40
051 Pinion Shaft	.50	091A Rack Lever	.40
052 Intermediate Pinion	.50	092 Shaft for 091	.10
053 Spur Gear Pinion	1.00	093 Shifter Con. Lever	.25
054 Bevel Gear for Main Shaft	2.25	094 Shifter Ring Lever	.25
054S Screw for 054	.03	095 Latch for Cut Out	.15
055 Collar for 054	.75	096 Shear Operating Lever	.15
3C Screw for 055	.03	097 Spring for 095	.05
056 Stand Old Style	1.00	098 Broken Joint Lever	.10
057 Gear Case	2.00	099 Latch Trip Bracket	.15
057S Set Screw for 057	.03	0100 Pin for 0106	.02
058 Cover	1.75	0101 Nut for 0103	.03
17 Screw for 058	.03	0102 Spring for 0103	.03
059 Spur Gear	1.75	0103 Spring Pin for 099	.05
060 Porcelain for 059	.03	0104 Box for Rack and Pinion	.25
061 Bobbin Stand	.25	0105 Lever for 0106	.05
061 Complete	3.00	0106 Take-up Shifter	.10
062 Three Pin Stand	.60	0107	.03
063 Take-up Frame Support	.20	0108 Twister Gear Shaft	.05
083X Screw for 063	.03	0109 Twister Pinion for Rack Fine	.25
064 Take-up Frame Rod	.25	0109s Twister Pinion for Rack coarse	.25
065 Nut for 064	.02	0109s Complete with Shaft	1.00
066 Frame Top	.20	0100t Twister Pinion Collar	.15
067 Frame Top	.50	0110 Rack Connect Link	.10
068 Thread Guide Arm	.05	0112 Collar for 0108	.02
069 Thread Loop Guide	.20	0113 Collar for 0108	.02
070 Frame Guide eye long	.10	0114 Slackner Lock Lever	.15
071 Frame Guide eye short	.10	0115 Rack for Twister	.25
072 Collar for 079	.10	0116 Shear Bell Crank Con. Link	.25
073 Take-up Clamp Collar	.25	0117 Pin Stud for 0116	.03
073 Complete	.35	0118 Box Stud for 096	.10
074 Clamp	.10	0119 Pin for 0118	.03
075 Yoke for 074	.10	0120 Adj. Stud for 0116	.05
076 Screw for 074	.03	0121 Nut for 0120	.02
077 Porcelain for 078	.03	0122 Spur Gear	1.75
078 Take-up	.15	0123 Gear Case	2.50
079 Spring	.10	0124 Cover	2.00
080 Con. Wire	.05	0125 Stud for 0126	.10
781 Bobbin Pin Washer	.15	0126 Intermediate pinion	.50
082 Bobbin Pin	.05	0127 Top Pinion for 051	.50
1082b	.05		
083 Yarn Guide Arm	.25		
084 Collar for 083	.15		

When ordering parts, please give the machine number, diameter of Needle Cylinder, and Number of Needles for which they are required. When ordering Sinkers, Points and Needles, please be particular to specify Style and Gauge, or else send samples. All Diameters are taken between the backs of opposite needles.



Needle Department

In connection with our Knitting Machine Works, we have established a most thoroughly equipped plant for making Latch Needles of superior quality, for all makes of Knitting Machines.

The Machinery has been selected and designed with the utmost care, and is operated by the best skilled help. Our aim is to furnish Needles that will give the best results and satisfaction.

WE ALSO MAKE TRANSFER POINTS, SINKERS
AND JACKS OF ALL KINDS OR SHAPES.

WE SOLICIT YOUR PATRONAGE.

Acme Knitting Machine and Needle Co.

FRANKLIN, New Hampshire.