

# LK-150 CONVERSION DIRECTIONS

1. Remove 6 needles at center of bed. Turn the machine over and remove the entire sponge bar by grasping it in the space left by the missing needles. The remaining needles will fall out when the sponge is removed.
2. Turn the machine upright and peel off the number strip.
3. Turn the machine over and remove the 4 screws and one of the needle bed bracer plates that connect the sections of the bed.
4. Wiggle the sections gently to separate the bed.
5. Join the new bed section between the two split pieces. There is a small "prong" that snaps one section into the next at the front of the piece. Secure the sections with two needle bed bracer plates. Press the new number strip into place on the top of the bed.
6. Lay in the new sponge and insert a few needles across the bed to hold it in place. Then replace all the needles taking care to lift the sponge by pressing upwards against adjacent needles to enable new needles to pass under the sponge without catching. You may find it faster to also keep one hand under the bed pressing up against the sponge when replacing so many needles at once. Make sure that the stopper colors on rollers alternate 10 pink/10 grey.
7. Attach additional bases for row counter and tension unit in the slots provided under the bed.