

Software updates: <http://www.silverknit.nl>

Quickstart installation instructions

Parts list SilverKnit

1. SilverKnit box
2. USB cable
3. Power Supply + power lead
4. CDROM with SilverKnit Utility, Pattern Explorer and USB drivers
5. This leaflet.

Software Installation

NOTE: INSTALL THE SOFTWARE BEFORE CONNECTING THE SILVERKNIT TO THE COMPUTER

1. Insert the SilverKnit installation CD in the CDROM drive
2. The SilverKnit installation program will start automatically
3. If autorun is not enabled on your computer, look for the CDrom and double click on Autoplay.exe in the root of the CD
4. Click on **Pattern Explorer (English)**
5. Follow the on screen instructions; the InstallShield installation wizard will guide you through the process
6. Click on **SilverKnit Software (English)**
7. Follow the on screen instructions; the InstallShield installation wizard will guide you through the process
8. Before clicking **Finish**, check that the installation of the USB drivers is completed. Move the installation dialog so you can see whether another program is covered by the installation dialog.
9. Restart your computer by clicking **Yes** on the restart dialog.

Note: It is recommended to install Silverknit Utility in the suggested folder.

Hardware Installation

1. Turn off your computer with the CDROM still in the CDROM drive
2. Connect the SilverKnit box to a free USB port of your computer using the USB cable provided
3. Turn on your computer with the CDROM still in the CDROM drive
4. In case the SilverKnit software installation starts, stop it by clicking on the cross in the top right hand corner
5. Windows will indicate "New hardware found"
6. Preferably let Windows search for the drivers
7. In case Windows doesn't find the drivers, indicate Windows that the drivers can be found on the CDROM
8. If Windows informs you that the drivers are not compatible, click on "Continue anyway"
9. The USB Serial Converter is now installed
10. Windows will indicate again "New hardware found"
 1. Preferably let Windows search for the drivers
 2. In case Windows doesn't find the drivers, indicate Windows that the drivers can be found on the CDROM
 3. If Windows informs you that the drivers are not compatible, click on "Continue anyway"
4. The USB Serial port is now installed
5. The installation is completed

Note: it is quite possible that above installation happens fully automatic.

Configuration

1. Start SilverKnit Utility
2. SilverKnit Utility will scan all com ports of your computer for a SilverKnit box
3. The configuration dialog of SilverKnit Utility will be displayed. An indication will be given for USB Com ports that have a SilverLink box connected.
4. Click on the com port that has a SilverKnit box connected.
5. If you forgot to turn on the SilverKnit box, turn it on and press **Refresh**
6. If you have multiple printers configured on your computer and you don't always want to print on the default printer, check "Show Print Dialog".
7. Click **OK** to confirm your settings
8. Configuration is now completed and the SilverKnit main dialog will be displayed

Note: On some computers a restart is required after installation of the USB drivers.